Transmittal Page

| Product | Title | Part Number |
|----------------------|----------------|-------------|
| WorkCentre 480/470cx | Service Manual | 701P14230 |
| Sta | Date | |
| Reprint | | June 1999 |
| | | |

NOTE: Please read WorkCentre 480/470cx Differences in Section 6 before servicing a WorkCentre 470cx machine.

This reprint contains the information in Service Manual 701P14810 for the WorkCentre 480cx as well as new information for servicing the WorkCentre 470cx and changes showing XE as the European operating company.

Section 1

Corrected title

Section 2

Updated Control Panel Messages to match latest F/W.

Updated RAP 2.2, 3.1 and 8.1 to show differences between 480 and 470.

Section 3

Updated IQRAP 1, 2, and 3 to include new troubleshooting information.

Section 4

Updated REP 1.2, 1.3, 4.1 and 4.2 to identify differences between 480 and 470.

Section 5

Updated PL 1.1, 2.1, 3.1 and 4.1 to identify changes due to differences between 480 and 470 as well as part changes since last pinting.

Section 6

Updated 480/470 product codes.

Updated Control Panel to identify new information and to include 480 and 470 differences.

Added WorkCentre 480/470cx Differences section.

Updated Accessories/Supplies/Consumables to show 480 and 470 differences.

Updated Specifications, Service Mode, Setting Up the System, F/W download instructions, System Data and Self Test definition.

Added Firmware Matrix and information.

Section 7

Updated to show 480 and 470 differences.

WorkCentre 480/470cx Service Manual

WorkCentre 480/470cx Service Manual

WorkCentre 480/470cx Service Manual

CAUTION

The Main PBA has a lithium battery which is not spared item. If the Main PWB fails, return the assembly to the X erox premises f or disposal in accordance with local regulations. DO NOT SHORT CIRCUIT THE BATTERY TERMINALS.

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



701P14230 June 1999

NOTICE

All service documentation is supplied to X erox external customers for informational purposes only. Xerox service documentation is intended for use by certified, product trained service personnel only. Xerox does not warrant or represent that such documentation is complete. Nor does Xero represent or warrant that it will notify or provide to such customer any future changes to this documentation. Service by the customer of equipment, or modules, components, or parts of such equipment may void any otherwise applicable Xerox warranties . If Customer services such equipment, modules, components, or parts thereof, Customer releases Xerox from any and all liability for actions by the Customer, and Customer agrees to indemnify, defend, and hold Xerox harmless from any third party claims which arise directly or in d irectly from su ch service.

Prepared by: Xerox Corporation Customer & Service Support 855 Publishers Parkwa Webster, NY. 14580

© 1999 by Xerox Corporation. All rights reserved. Xerox and all Xerox pro d u c ts me n t i o n e d in this publication are registered trademarks of the Xerox Corporation.

Revision Control List

| Product WorkCentre 480/470cx | Title Service Manual | Part Number 701P14230 |
|------------------------------|-------------------------|--------------------------|
| | | |

| Page | Revision | Page | Revision | Page | Revision | Page | Revision | Page | Revision | Page | Revision |
|-------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|
| Title | | 3-1 | | 5-1 | | 7-1 | | | | | |
| ii | | 3-2 | | 5-2 | | 7-2 | | | | | |
| iii | | 3-3 | | 5-3 | | 7-3 | | | | | |
| iv | ļ . | 3-4 | | 5-4 | | 7-4 | | | | ļ | |
| v | | 3-5 | | 5-5 | | 7-5 | | | | | |
| vi | 1 | 3-6 | | 5-6 | | 7-6 | | | | | |
| | | | | 5-7 | | 7-7 | | | | - | |
| 1-1 | | 4-1 | | 5-8 | | 7-8 | | | | | |
| 1-2 | | 4-2 | | 5-9 | | 7-9 | | | | | ļ |
| 1-3 | | 4-3 | | 5-10 | | 7-10 | | | | | |
| 1-4 | | 4-4 | | | | 7-11 | | | | ļ | |
| 1-5 | | 4-5 | | 6-1 | | 7-12 | | | | 1 | |
| 1-6 | | 4-6 | | 6-2 | | 7-13 | | | | 1 | |
| 1-7 | | 4-7 | | 6-3 | | 7-14 | | | | | |
| 1-8 | | 4-8 | | 6-4 | | 7-15 | | | | | |
| 1-9 | | 4-9 | | 6-5 | | 7-16 | | | | | İ |
| 1-10 | | 4-10 | | 6-6 | | · · | | | j j | | |
| 1-11 | | 4-11 | | 6-7 | | | | | | ĺ | |
| 1-12 | | 4-12 | | 6-8 | | | | | | | |
| | | 4-13 | | 6-9 | | | | | ŀ | 1 | |
| 2-1 | | 4-14 | | 6-10 | | | | | | | |
| 2-2 | | 4-15 | | 6-11 | | | | | | | |
| 2-3 | 1 | 4-16 | | 6-12 | | l | | | | | } |
| 2-4 | | 4-17 | | 6-13 | | | | | | | |
| 2-5 | | 4-18 | | 6-14 | | | | | 1 | | |
| 2-6 | | 4-19 | | 6-15 | | | | | | | ļ |
| 2-7 | | 4-20 | | 6-16 | | | | | | | |
| 2-8 | | 4-21 | | 6-17 | | | | | | | |
| 2-9 | | 4-22 | | 6-18 | ļ | | | | | ļ | |
| 2-10 | | 4-23 | | 6-19 | | | | | | | |
| 2-11 | | 4-24 | | 6-20 | | | | | | | |
| 2-12 | | | | 6-21 | | | | | | | |
| 2-13 | | | | 6-22 | | | | | | | |
| 2-14 | | | | | | | | | | | |
| 2-15 | | | | | | | | |] | | |
| | | | | | | | | | | | |

Table of Contents

| | oduction |
|------------|---------------------------------------|
| | out this manual v |
| | anization v |
| | v to use this manual v |
| Mai | nual Revision Symbols vi |
| | del Distinction vi |
| | minology and Symbols vi |
| Mo | dificationvi |
| | |
| 1. | Service Call Procedures 1-1 |
| | Section Contents1-1 |
| _ | |
| 2. | |
| | Procedures 2-1 Section Contents2-1 |
| | Section Contents2-1 |
| 3. | Image Quality Repair |
| ٥. | Analysis Procedures 3-1 |
| | Section Contents3-1 |
| | Section Contents |
| 4. | Repair/Adjustment4-1 |
| •• | Section Contents4-1 |
| | Codion Concerno |
| 5. | Parts Lists 5-1 |
| | Section Contents5-1 |
| | |
| 6. | General Procedures |
| | Information 6-1 |
| | Section Contents |
| | |
| 7 . | Wiring Data 7-1 |
| | Section Contents7-1 |

Introduction

About this manual

This ma nual is part of the multinational documentation that is structured in a specified Xerox format.

Organization

The Xerox Document WorkCentre Service Manual is the primary document used for repairing and maintaining the family of products. The manual contains this information divided into the following sections:

Section 1 Service Call Procedures

This section is used to identify the first audible or visual symptom for the problem. procedures will then direct you to a RAP or they identify a faulty component or subassembly.

Section 2 Repair Analysis Procedures

This se c tion co n t ains Repair Analysis Procedures (RAPs). You will be directed to this section to isolate a faulty component or subassembly.

Section 3 Image Quality Repair Analysis Procedures

This section con tains Image Quality Repair Analysis Procedures (IQRAPs) and Image Quality samples. You will refer to this section to identify test pattern samples or isolation procedures for common image quality defects.

Section 4 Repair / Adjustment

This se ction contains the instructions for removal, replacement, and adjustment of the spared parts within the machine.

Section 5 Parts List

This section consists of illustrations and part number lists. Any part that is spared or any part that must be removed to access a spared part is illustrated. Common hardware is shown as a letter callout.

Section 6 General Procedures / Information

This se ction contains general procedures, product specifications, supplemental tools and supplies, modification information, and installation instructions.

Section 7 Wiring Data

This section contains illustrations and lists of the signals and connectors. The illustrations show the power, gro u nd, and the control signal distribution. The lists show the signals and pin assignments for all connectors.

How to use this manual

Start all service calls and end all service calls with the Service Call Procedures, Section 1. Perform Initial Actions and the System Check to identify a symptom.

Follow the instructions provided within the Service Call Procedures and proceed to the appropriate section of the manual.

After the repair is complete, verify the repair with the System Check.

Manual Revision Symbols

Revision pages con taining the latest service information will be sent to you so that you can update your service manual. When a partial revision is distributed, the change swill be identified on each page.

Text

Black vertical bar at the beginning of the text for partial revisions.

When a partial revision or a complete manual revision is distributed, the changes will also be identified as follows:

Page

The date of issue on the bottom of each page.

Manual

An updated revision control list. This list will identify the latest d ate

each page.

Model Distinction

TEXT

If different parts or actions exist because of different models, the model distinction (xxx) will identify the appropriate part or action.

Example 1). - - - - - xxx: The sequence is Example 2) - - - - - The sequence is . . . (xxx) .

Terminology and Symbols

The following is the terminology and symbols that are used in this manual for Warnings, Electrostatic Device or general Cautions, and Notes.

Electro Static Discharge



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



WARNING

Improper operation may result in injury to a person.

CAUTION

Improper operation may result in machine damage.

NOTE: Hints or other information that may assist the user.

Modification

The machine serial number listed will identify the earliest number of the change on the manufactured machine.

1. Service Call Procedures

Section Contents

| Introduction | 1-1 |
|------------------------------------|------|
| Electro Static Discharge | 1-1 |
| Initial Actions | |
| System Check | 1-4 |
| Subsystem Cleaning and Maintenance | 1-12 |
| Final Actions | 1-12 |

Introduction

This chapter describes the tasks that a service technician m complete when responding to a problem at a customer site. Collectively, these tasks are the Service Call Procedure.

These procedures direct you to other sections when diagnosing and repairing the WorkCentre. You should always return to this section to continue with the Service Call Procedure.

Complete the procedures in this chapter in the order given. By ignoring the sequence of procedures, you may diagnose a symptom incorrectly and cause the customer undue frustration and expense.

Initial Actions are used to gather information regarding the performance of the machine and prepare the product for servicing.

System Checks are used to verify the normal operation of the machine. In the Y/N steps of the system checks, a Yes response will lead you to the next step. A No response will indicate the next step to perform or will direct you to a RAP.

RAPs will provide the instructions to isolate the faulty part or provide a list of suspect parts, when isolation is not possible.

Subsystem maintenance contains routine maintenance procedures.

Final Acti describe procedures you carry out when completing the service call.

Electro Static Discharge




Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage. THIS PAGE INTENTIONALLY LEFT BLANK

Initial Actions

If possible perform the following before you begin the initial actions

- If you are performing on-site service, print the System Data List. This will provide you with the customer's settings to allow you to restore them later.
- If you are performing on-site service, print out Telephone Numbers List.
- Enter Service Mode by pressing , #,
 1, 9, 3, 4. LCD displays T in the lower right corner.
- Reset machine to defaults.
 5.
- Enter Service Mode again.
 Then enter fax name and ID number.




System Check

The initial actions you performed on the previous page performed a quick initial check of the power system, circuit boards, control panel, paper feed, and the printer engine.

After you perform the Initial Actions, perform a system check using the flowcharts on the following pages.

The System Check will help identify any problems and refer you to the appropriate RAP or REP


After you have repaired any problem, perform this system check again, and then perform the Final Action procedure.




System Check (continued)

Continue the Initial Actions flowchart on this page to check the scanner assembly, LCU, and fax capabilities.

System Check: Copier Test




System Check: Copier Test (continued)




System Check: Send Fax Test Fax a document to a known good fax machine and using a known good telephone line. Scanner motor does not NO Place a document in the ADF. activate or document feeds incorrectly. Go to Document The document feeds part way Feed RAP 5.1. through the scanner and stops. YES The following message appears NO on the LCD: MAR - 01 - 1999 100% DOCUMENT READY YES If no message displays go to Control Panel RAP 7.1. Dial the first digit of the remote NO Fax number. LCD displays: If any other message displays, **TEL:1** go to Control Panel Messages RAP 1.1. YES Dial the remaining digits of the remote fax machine. Then NO press (>. Display shows: **SCAN TO MEMORY** PAGE 1 100% YES The document feeds all the way through the scanner. The NO scanner motor stops after the Go to Document Feed RAP 5.1. document ejects. YES Continued on following page


System Check: Send Fax Test (continued)




System Check: Receive Fax test



System Check: Receive Fax test (continued)



System Check: Receive Fax test (continued):



Subsystem Cleaning and Maintenance

The printer and scanner require periodic cleaning. When you are servicing the WorkCentre, perform the following procedures.

Clean the following printer engine parts

| Description | Procedure |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Cover | Clean using a lint free tissue and water or Formula A. |
| Paper Feed and Document Feed Roller | Clean using a lint free tissue, water, and Film Remover. |
| Maintenance Station | Clean using a lint free tissue and water. |
| Carriage Shaft | Inspect the Shaft for damage (abrasions, wear marks, burrs). Clean the guide rod using Xerox film remover and a lint free cloth. |
| | Next, use a lint free cloth to apply a thin film o grease 70H44 to the rail |
| ADF Rubber | Inspect for wear and replace as required. |

Check all rubber items for wear and hardness.

If worn or harder than normal, replace as required.

Final Actions

Clean the machine's exterior

Clean the exterior of the WorkCentre using a lint free cloth and water or Formula A.

Restore the customer's settings

Do not restore any settings that you suspected were the cause of any problems.



2. Subsystem Repair Analysis Procedures

Section Contents

| RAP 1.1 Control Panel Messages | - 2-2 |
|---------------------------------------|--------|
| RAP 2.1 AC Power Check | - 2-4 |
| RAP 2.2 Power Supply DC Voltage Check | - 2-5 |
| RAP 3.1 Paper Feed | 2-7 |
| RAP 4.1 Carriage Motor | - 2-8 |
| RAP 4.2 Ink Cartridges | 2-9 |
| RAP 5.1 Document Feed | 2-10 |
| RAP 6.1 Communications | 2-11 |
| RAP 6.2 PC Connectivity | 2-12 |
| RAP 7.1 Control Panel | 2-16 |
| RAP 8.1 ADF Door Interlock | 2-17 |
| RAP 9.1 ROM Test | - 2-20 |

Overview

This section includes repair analysis procedures (RAPs). These procedures aid you in diagnosing the defective subsystem. The RAPs described in this section continue the fault analysis to the replacement unit level.

The RAPs include some corrective information. These RAPs may lead to other RAPs or Repair and Replacement Procedure (REPs).

Electro Static Discharge



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

RAP 1.1 Control Panel Messages

A subsystem failure on the machine will, in most cases, report a message on the control panel.

This RAP consists of a listing of messages and other symptoms that direct you to a RAP to further isolate the problem

This section does not list all possible messages or error codes that appear. Most messages are self explanatory.

See the User Guide for other messages not listed.

WorkCentre Control Panel Messages

| Message | Meaning | Operator Action | Technician Action |
|-----------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| (R) CARTRIDGE EMPTY (L) CARTRIDGE EMPTY ALL CARTRIDGES EMPTY | The WorkCentre did not detect a Cartridg installed in the position called out in th display. | Remove and reinstall the Cartridge per the User Guide instructions | Go to RAP 4.2. |
| CHECK CARTRIDGE | The Cartridge is not correctly installed in the machine. | Remove and reinstall the Cartridge per the User Guide instructions | Go to RAP 4.2. |
| SEND ERROR or RECEIVE ERROR | There is a fax communications problem | Try the operation at a later time. Turn on ECM and try again. | Go to RAP 6.1. |
| COVER OPEN (480 only) | The Cartridge Cover is open. | Close the Cartridge Cover. | Go to RAP 8.1. |
| DOCUMENT JAM | The document did not feed proper through the ADF and Scanner. | Ensure Control Panel is closed. Clear and clean the feed rollers and ADF Rubber Pad. Reload the documents and try again. | Go to RAP 5.1. |
| INK LOW | The Cartridge may be low of ink. | Install the appropriate cartridge | Go to RAP 4.2. |
| LINE ERROR | Your machine cannot connect with the remote site, or it has lost contact becaus of a problem on the phone line. | Try the operation at a later time. Turn on ECM and try again. | Go to RAP 6.1. |
| LOAD DOCUMENT | You have attempted to set up an operation that requires loading a document. | Ensure Control Panel is closed. Load a document and try again. | Go to RAP 5.1. |
| NO LINE CONNECTION | The WorkCentre was not able to detect a dial tone. | Make sure the (LINE) connection is properly connected to a telephone line. | Go to RAP 6.1. |
| NO PAPER ADD PAPER THEN PRESS > | The WorkCentre is out of paper. | Load up to 100 sheets of 20lb. paper in the APF paper tray. Ensure guides are not pinching paper. After loading paper press any of the four arrow buttons. | Go to RAP 3.1. |
| PAPER JAM | The print media did not feed properly through the printer. | Press STOP to remove the print media is possible Clean the rollers with a lint free towel moistened with water or alcohol. Reload the print media according to the User Guide instructions. | Go to RAP 3.1 |
| POWER FAILURE | A power failure occurred with documents stored in memory which caused a Power Failure Report to be printed out automatically when power was restored. | Examine the Power Failure Report and determine what was in process at the time of the power failure. Perform the operation that was not successful due to the power failure. | Go to Initial Actions in Section 1 if you suspec there is a problem with the machine. |
| RETRY REDIAL ? | The WorkCentre was not able to connect to the remote machine or encountered a busy signal. | Wait and let the machine redial or remove you documents and try the operation later. | Go to RAP 6.1. |

RAP 2.1 AC Power Check

Note: If any of the AC voltage measurements are not within the specifications, a qualified electrician retained by the customer must make the required repairs. If you later find the condition is not corrected, inform your manager in writing of the improper wiring.

 110 VAC: Voltage at the wall receptacle must be from 90 VAC to 132 VAC between AC hot and AC neutral and between AC hot and GND. Voltage should be less than 3 VAC between GND and neutral (see Figure 2-1).

AC Neutral GND AC Hot




Figure 2-1. 110 VAC Receptacle

2. **220 VAC:** Voltage at the wall receptacle is 180 VAC to 264 VAC between live and neutral and between live and earth.

Voltage should be 3 VAC or less between earth and neutral (Figure 2-2).




Figure 2-2. 220 VAC Receptacle

- EUROPE (excluding the UK): Voltage at the wall receptacle is 180 VAC to 264 VAC between supply pins. Voltage between one supply pin and earth is 197 VAC to 264 VAC. Voltage between the other supply pin and earth is 3 VAC or less (Figure 0-4).
 - If the voltage is not correct, notify the customer of the electrical requirements.
- 4. If the voltage is correct, go to RAP 2.2: Power Supply DC Voltage Check.

RAP 2.2 Power Supply DC Voltage Check

See Parts List 3.1

- 1. Prepare to test the power supply by performing the following REPs:
 - REP 1.2 Rear Cover Assembly
- 2. Apply power to the machine.

WARNING

There are exposed areas of high voltage on the power supply. Use caution when working in this area with the multimeter probes.

3. Using a multimeter, place the Common lead to the GND terminal at the left front corner of the power supply (viewed from the rear).

Place the Positive lead to the following pins on P/J6 on the Main PBA:

- Pin 6-1 (Red Wire) = +4.35 VDC to +4.65 VDC
- Pin 6-3 (Red Wire) = +11.1 VDC to +12.3 VDC
- Pin 6-6 (Blk Wire) = +28.5 VDC to +31.5 VDC

Result: All voltages are within tolerances?

No: Go to step 4.

Yes: Power supply is good.

- 4. Disconnect power from the machine
- 5. Carefully disconnect Power Supply connector J6 from the Main PBA.
- 6. Apply power to the machine.
- 7. Perform step 3 voltage checks Result: All voltages are within tolerances?

No: Replace the power supply <u>REP 3.4 Power Supply</u>.

Yes: There is no problem with the power supply. The out-of tolerance voltage readings you encountered may be a result of a problem with a circuit board or motor. Go to Step 8.

8. Disconnect J2 from the Main PBA.

Perform step 3 voltage checks.

Result: All voltages are within tolerances?

No: Disconnect J1 from the Main PBA. Go to Step 9.

Yes: There's a problem with the Scan Motor. Replace REP 3.3 Scan Motor/Gear Assembly.

9. Perform step 3 voltage checks.

Result: Power supply readings are within specification?

No: Disconnect J3 from the Main PBA. Go to Step 10.

Yes: There's a problem with the control panel. Replace REP 1.4 Control Panel Assembly.

10. Perform step 3 voltage checks

Result: Power supply readings are within specification?

No: Disconnect CN1 from the Main PBA. Go to Step 11.

Yes: There's a problem with the CIS assembly. Replace REP 3.2 CIS (Contact Image Sensor).

11. Perform step 3 voltage checks

Result: Power supply readings are within specification?

No: Disconnect J7 from the Main PBA. Go to Step 12.

Yes: There's a problem with the Parallel Cable Interface PBA. Replace REP 3.6 Parallel Cable Interface PBA.

12. Perform step 3 voltage checks

Result: Power supply readings are within specification?

No: Disconnect J4 from the Main PBA. Go to Step 13.

Yes: There's a problem with the LIU PBA. Replace REP 3.5 LIU PBA.

13. Perform step 3 voltage checks
Result: Power supply readings ar within specification?

No: Disconnect JP4 from the Main PBA. Go to Step 14.

Yes: There's a problem with the Paper Feed Motor. Replace REP 4.9
Paper Feed Motor Assembly.

14. Perform step 3 voltage checks
Result: Power supply readings are within specification?

No: Disconnect J5 from the Main PBA. Go to Step 15.

Yes: There's a problem with the Carriage Motor. Replace it.

15. Perform step 3 voltage checks Result: Power supply readings are within specification?

No: Disconnect JP1, JP2, and JP3 from the Main PBA. Go to Step 16.

Yes: There's a problem with the Speaker. Replace REP 1.3 Top Cover Assembly.

16. Perform step 3 voltage checks
Result: Power supply readings ar within specification?

No: WorkCentre 470cx: Replace REP 4.5

Main PBA. End of RAP for 470cx.

No: WorkCentre 480cx: Disconnect J8 from the Main PBA. Go to Step 17.

Yes: There's a problem with the Carriage Assembly or Ink Cartridges. Replace the Cartridges, then REP 4.4 Carriage Assembly. End of RAP for 470cx.

17. Perform step 3 voltage checks
Result: Power supply readings are within specification?

No: Disconnect J10 from the Main PBA. Go to Step 18Yes: There's a problem with the APF Tray Empty Sensor. Replace REP 4.2 APF Tray Assembly.

18. Perform step 3 voltage checks.

Result: Power supply readings are within specification?

No: Replace REP 4.5 Main PBA.

Yes: There's a problem with the Cartridge Cover Interlock. Replace REP 1.3 Top Cover Assembly.

RAP 3.1 Paper Fee

See Parts List 4.1.

This RAP will help isolate media feed problems in the printer.

If paper or other media is not feeding or partially feeding into the printer, check for the following:

- Ensure the specified media is being used with the WorkCentre
- Damaged media
- Damaged or dirty paper feed roller and items in the paper path.

WorkCentre 470cx go to Step 4.

WorkCentre 480cx go to Step 1.

Correct any of these problems if they exist.

 Power on the WorkCentre without paper loaded in the APF Tray Assembly.

Result: The following message appears on LCD:

NO PAPER

No: Make sure the APF Paper Empty Sensor is not jammed in the down position. If the APF Tray Assembly harness is okay, replace the Main PBA REP 4.5 Main PBA.

Yes: Continue with Step 2.

- 2. Add paper to the APF Tray Assembly.
- 3. Check wire harness from the Main PBA J8 to the APF Paper Empty Sensor.

Result: Harness and connections appear good and NO PAPER message goes away?

No: Reconnect the wire harness, or

replace REP 4.2 APF Tray Assembly.

Yes: Continue with Step 4.

4. Check the position of the paper feed cam and manually rotate it one complete revolution. Note action of cam

Result: Cam mechanism operates freely?

No: Replace REP 4.2 APF Tray Assembly.

Yes: Continue with Step 5.

- Check the Paper Path Sensor and Actuator to ensure proper actuation when paper is feeding.
- Check voltage between GND and J4-1, J4-2, J4-3, and J4-4 on the Main PBA.

Result: Voltage is between 26 VDC and 29 VDC?

No: Go to RAP 2.2: Power Supply DC Voltage Check.

Yes: Continue with Step 7.

Replace <u>REP 4.9 Paper Feed Motor Assembly</u>.
 If this does not solve the problem, replace <u>REP 4.5 Main PBA</u>.

NOTE: You may choose to check the paper feed motor for an open motor winding.

Disconnect P4. Table 2-1, gives the resistance values between pins on the motor wiring harness.

Table 2-1. Paper Feed Motor Winding Resistance

| 1st Pin | 2nd Pin | Resistance |
|---------|---------|--------------|
| 1 | 2 | 11 - 13 ohms |
| 3 | 4 | 11 - 13 ohms |

If the resistance is too low, then there is a short in the paper feed motor winding. If the resistance is infinite, or too high, then there is an open in the motor winding.

RAP 4.1 Carriage Motor

See Parts List 4.1

 Check for a loose or damaged wire harness from the Main PBA JP4 to the Carriage Motor.

Result: Harness and connectors appear good.

No: Reconnect the harness, or replace the

Carriage Motor as required.

Yes: Continue with Step 2.

2. Check the voltage between GND and JP4-2 on the Main PBA.

Result: Voltage is between +27 VDC and +32 VDC?

No: Go to RAP 2.2: Power Supply DC Voltage Check.

Yes: Continue with Step 3.

3. Replace <u>REP 4.4 Carriage Assembly</u>. If this does not solve the problem, replace <u>REP 4.5 Main PBA</u>.

NOTE: You may also choose to check the Carriage Motor for an open motor winding.

Disconnect JP4. Table 2-2. gives the resistance values between pins on the Carriage Motor wiring harness.

Table 2-2. Carriage Motor Winding Resistance

| 1st Pin | 2nd Pin | Resistance |
|---------|---------|-------------|
| 1 | 2 | 10 - 20 ohm |

If the resistance is too low, then there is a short in the motor winding. If the resistance is infinite, or too high, then there is an open in the motor winding.

RAP 4.2 Ink Cartridges

See Parts List 4.1

1. Check that the ink cartridges are properly seated.

Result: Cartridges are properly seated and contain ink

No: Correct the condition.

Yes: Continue with Step 2.

2. Check the ribbon cables from JP1, JP2 and JP3 on the Main PBA. Make sure they are not damaged or loose.

Result: The cables and connections are good?

No: Reconnect the cables, or replace as

required.

Yes: Continue with Step 3.

3. Power on the unit.

Result: Power-on test reports cartridge problems?

No: Problem corrected. End of RAP.

Yes: Go to step 4.

4. Check the voltage at the Main PBA connector J6-3 and GND.

Result: Voltage is between +11 VDC and +12.5 VDC?

No: Go to RAP 2.1.

Yes: Replace REP 4.5 Main PBA. If this

does not correct

the problem, replace REP 4.4

Carriage Assembly.

RAP 5.1 Document Fee

See Parts List 1.1, 2.1 & 3.1.

This RAP will help isolate document fee problems in the ADF and Scanner.

1. Document tries to feed.

No: Go to Step 5.

Yes: Inspect the documents being used to see if they meet document specifications.

- Check the White Roller, Scan Drive Roller and ADF Roller assemblies for wear, damage, contamination or hardness
- Check the ADF Rubber Pad for excess wear or contamination.
- Clean the rollers and pad with a lint free towel moistened with water or alcohol.
- 2. Try to make a copy.

Result: Document now feeds?

No: Check the ADF and scanner paper path for burrs and abrasions.

Correct problems found. Continue with Step 3.

Yes: Problem corrected.

3. Try to make a copy.

Result: Document now feeds?

No: Replace REP 2.1 ADF Rubber Pad. If problems still occur, replace REP 3.1 Rollers (ADF and Drive Rollers, and Document Exit Shaf Assemblies and REP 1.1 White Roller Assembly. Continue with step 4.

Yes: Problem corrected.

4. Try to make a copy.

Result: Document now feeds?

No: Continue with Step 5

Yes: Problem corrected.

5. Open the Control Panel and check that the two sensor actuators, located on the back of the Control Panel, move freely

Result: Switches operate freely?

No: Correct the condition, or replace REP 1.4 Control Panel Assembly.

Yes: Continue with Step 6.

6. Check the wiring harness from the Main PBA connector J2 to the Scanner Motor.

Result: Wiring harness is securely connected?

No: Connect the wiring harness securely to connector J2.

Yes: Continue with Step 7.

7. Power on the unit. Check the voltage from Main PBA connector J2-1, J2-2, J2-3, J2-4 and GND

Result: Voltage is +27 VDC in standby and goes toward +15 VDC during Scanner Motor drive.

No: Perform RAP 2.2: Power Supply DC Voltage Check.

Yes: Replace <u>REP 3.3 Scan Motor/Gear Assembly</u>. If this does not solve the problem, replace REP 4.5 Main PBA.

NOTE: You may choose to check the Scanner Motor for an open motor winding.

Disconnect J2. Table 2-3. gives the resistance values between pins on the scanner motor wiring harness.

Table 2-3. Scanner Motor W
Resistance

| 1st Pin | 2nd Pin | Resistance |
|---------|---------|------------|
| 1 | 2 | 5 - 7 ohms |
| 3 | 4 | 5 - 7 ohms |

If the resistance is too low, then there is a short in the scanner motor winding. If the resistance is infinite, or too high, then there is an open in the motor winding.

RAP 6.1 Communications

See Parts List 3.1.

 Check the wire harnesses and connections from the Main PBA connector J7 to the LIU PBA, LIU connector P3 to telephone line connector, and the telephone connection.

Result: Connections secure?

No: Reconnect wire harnesses as

required.

Yes: Continue with Step 2.

2. Is Speaker volume turned on?

No: Turn on speaker.

Yes: Continue with step 3.

3. Enter Service Mode by pressing , #, 1, 9, 3, 4.

4. Press ≡, 04, ♠, ♠, V, ♠, Ø.

Run the modem test. Listen for tones and signals to vary as you cycle through the test.

Result: Test passed?

No: Disconnect J5 to Speaker. The resistance of the Speaker coil

from J5-1 to J5-2 is 8 ohms. If

incorrect, replace

REP 1.3 Top Cover Assembly.

Yes: Continue with Step 5.

5. In Service Mode, run the DTMF test by pressing

■ , 04, ♦ . Press all keypad digits and check display for correct response.

Result: Test passed?

No: Replace REP 4.5 Main PBA.

Yes: Continue with Step 7.

6. Connect the machine to a known, good telephone line.

Send and/or receive a fax.

Result: Machine transmits and/or receives the fax

No: Replace REP 3.5 LIU PBA and retest. If this does not solve

the problem, replace REP 4.5 Main PBA.

Yes: End of RAP.

RAP 6.2 PC Connectivity

This RAP tests the communication betwee the WorkCentre's parallel port (Centronics) and the PC.

- Check the cables from Main PBA connector CN1 to the Parallel Cable Interface PBA CN1. From Parallel Cable Interface CN2 to the customer's PC.
 - The cable must be an IEEE 1284 compliant cable no longer than 25 feet.
 - The cable must be securely connected to the WorkCentre Centronics port and the customer's PC parallel port.
 - The connection must be a direct connection, i.e., not routed through a switch box or other device.
- 2. Power on the WorkCentre.
- 3. At the PC, exit Windows to DOS.
- 4. At the customer's DOS system prompt, type the following:

Result: Text "Testing 1234" prints on the WorkCentre?

No: Recheck the parallel cable and cable connections. Replace the cable with a known good cable. If this does not correct the problem, replace REP 4.5

Main PBA, then REP 3.6 Parallel
Cable Interface PBA.

Yes: End of RAP. Exit DOS and return to Windows.

RAP 7.1 Control Panel

See Parts List 4.1.

This RAP will isolate a Control Panel problem to the failed component.

1. Power on the unit.

Check the voltage between J1-2 and J1-1 on the Main PBA.

Result: Voltage is between +4.35 VDC and +4.65 VDC?

No: Perform RAP 2.2: Power Supply DC

Voltage Check.

Yes: Replace REP 1.4 Control Panel

Assembly. If this does not correct the problem, replace REP 4.5

Main PBA

RAP 8.1 Cartridge Cover Interlock (480 Only)

See Parts List 1.1.

1. Check for a loose or damaged cable from J10 on the Main PBA.

Result: Harness and connections appear good?

No: Reconnect the harness, or replace REP 1.3 Top Cover Assembly.

Yes: Continue with Step 2.

 Disconnect J10 from the Main PBA Check for continuity between J10-1 and J10-2 with the ADF Door closed and infinity with the ADF Door opened.

No: Replace <u>REP 1.3 Top Cover</u> Assembly.

Yes: Replace REP 4.5 Main PBA.

RAP 9.1 ROM Test

This RAP tests the WorkCentre's ROM
The WorkCentre is tested during system
startup. However, you can run a ROM test
from the service menu.

1. Power on the machine.

2. In the Service Mode, perform the ROM test by pressing ☐ , 01, V, V, V, V, V, V, V, ♦

Result: Test passed?

No: Replace REP 4.5 Main PBA.

Yes: End of RAP.

THIS PAGE INTENTIONALLY LEFT BLANK

3. Image Quality Repair Analysis Procedures

Section Contents

| Introduction | 3-1 |
|------------------------------|-----|
| IQRAP 1 Image Defect Table 3 | 3-2 |
| IQRAP 2 Print Quality: | 3-4 |
| IQRAP 3 Scan Quality: | 3-5 |

Introduction

The Image Quality section is used to identify image quality problems.

IQRAP 1 Image Defect Table

Print SELF TEST:

- 1. Load paper into the APF.
- 2. Press ■, 13, ♦ .
- 3. Examine the SELF TEST for quality defects listed in Defect column of the following table.

Generally quality problems are caused by:

- · non-approved paper or other media
- out-of-alignment Cartridge
- · a defective or dirty Cartridge
- incorrect type of Cartridge installed
- paper feed problems
- defective Encoder
- · CIS aging
- · dirty roller
- · dirty platen

Use your best judgement to determine the cause of a quality problem.

Make a COPY:

- 1. Load 82P151 into the ADF.
- 2. Press , .
- 3. Examine the copy for quality defects listed in column 1 of the following table.

| Defect | Cause | Solution |
|-----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Blank print | Print head | Remove and check for tape covering th Cartridge print head nozzles. Reinstall th Cartridge. Press , 13, V, V, and to clean and restore the Cartridge. If the problem still exists, replace the Cartridge. Go to IQRAP 2. |
| White horizontal lines and streaks | The Cartridge nozzles may be blocked. | Press , 13, V, V, to clean and restore the Cartridge. If the problem still exists, replace the Cartridge. Go to IQRAP 2. |
| Print is faint or missing. | A non-recommended paper is being used or the paper is damp. Defective Cartridge. The ink supply may b nearly empty. The Cartridge nozzles may be blocked. | Replace the paper. Press , 13, V, V, and to clean th Cartridge. Print a new SELF-TEST. If the print is still faint, perform the cleaning procedure 2 more times. If the problem still exists, replace the Cartridge. Go to IQRAP 2. |
| Blurry or jagge vertical line | Cartridge is out of alignment. Paper | Align the Cartridge (), 13, V, () an perform adjustment. If the problem still exists, replace the Cartridge. Use the opposite side of the paper. Go to IQRAP 2. |
| Print image is clipped or off the edge of the media | Print off the edge of the media Document margins may exceed printer margins | Make sure the printer driver setup has the correct selection for media size and type Adjust the margins in the application as necessary. |
| Vertical white lines on print after copy or scan | Foreign matter on CIS glass or plastic platen | Clean both the CIS assembly glass and White Roller. Examine the CIS assembly and White Rollerfor scratches, cuts and wear. Align the Cartridge , 13, V, and perform adjustment. Go to IQRAP 2 for print problems. Go to IQRAP 3 for scan problems. |

| Defect | Cause | Solution |
|------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Vertical offse overtype (a line of type prints over part of the preceding line) | A damaged or strippe gear or roller is preventing the media from advancing properly. | Replace the gear or roller. If that does no solve the problem go to RAP 3.1. |
| Vertical black lines during copy or scanning. | Damaged, contaminated or defective CIS. | Clean the CIS, Platen Glass and White Roller. Perform ADJ 3.1 Adjust CIS Shading. Go to IQRAP 3. |
| Black Copy | CIS defective | Go to IQRAP 3. |
| Smudged or dark characters | Paper incorrect type Paper not feedin straight. Cartridge may need cleaning. | Replace the paper. Press : 13, V, V, and to clean th Cartridge. Print a new SELF TEST. If the print is still faint, perform the cleaning procedure 2 more times. If the problem still exists, replace th Cartridge. |
| Incorrect colors printed on received FAX and during copy mode. | Incorrect type of print cartridge installed fo operation being performed. Such as: Photo cartridge installed during normal printing | Install the proper print cartridge required for the type of operation being accomplished Go to IQRAP 2. |

IQRAP 2 Print Quality

See Parts List 4.1

- 1. Remove the Cartridges
- 2. Check that the proper print cartridges are install for the type of print required.
- 3. Clean the head of the cartridge with a lint free cloth moistened with warm water.
- 4. Install the Cartridges.
- 5. Clean the Cartridges using the CLEAN HEAD procedure. , 13, V, V, ♦ . Do this 2 times.
- 6. Make a test print.

Result: Test print is blank

No: Go to step 12.

Yes: Continue with Step 7.

- 7. Replace the defective Cartridge.
- 8. Make a test print.

Result: Test print is still blank?

No: End of RAP.

Yes: Continue with Step 9.

- Check the Carriage ribbon cables JP1, JP2 and JP3 from the Main PBA f damage. Reconnect or replace Carriage Assembly as required 17Carriage Assembly.
- 10. Make a test print.

Result: Test print is still blank?

No: End of RAP.

Yes: Continue with Step 11.

- 11. Replace <u>REP 4.4 Carriage Assembly</u>. If problem has not been corrected replace <u>REP 4.5 Main PBA</u>.
- 12. Perform the Cartridge ARRANGE ALIGNMENT procedure.

■, 13, V, ◆.

IQRAP 3 Scan Quality

See Parts List 3.1, 4.1.

An entirely black print of a scanned document or black streaks where white should have been is indicative of a CIS, scanner problem.

- 1. Power on the unit.
- 2. Check the voltage between J3-3 and GND on the Main PBA.

Result: Voltage is between +4.35 VDC to +4.65 VDC.

No: Perform RAP 2.2: Power Supply DC Voltage Check on page 2-12.

Yes: Continue with Step 3.

3. Check the voltage between J3-12 and GND on the Main PBA.

Result: Voltage is between +11.1 VDC and +12.3 VDC?

No: Perform RAP 2.2: Power Supply DC Voltage Check on page 2-12.

Yes: Check CIS harness and replace if damaged. Otherwise, replace REP 3.2 CIS (Contact Image Sensor). If this does not correct the problem, replace REP 4.5 Main PBA.

THIS PAGE INTENTIONALLY LEFT BLANK

Section Contents

Introduction

| Introduction | 1 | 4-1 |
|--------------|------------------------------------|--------|
| REP 1.1 | White Roller Assembly | |
| REP 1.2 | Rear Cover Assembly | |
| REP 1.3 | Top Cover Assembl | 4-4 |
| REP 1.4 | Control Panel Assembl | |
| REP 2.1 | ADF Rubber Pad | |
| REP 3.1 | Rollers (ADF and Drive Rollers, | |
| | and Document Exit Shaft Assemblies |)4-7 |
| REP 3.2 | CIS (Contact Image Sensor) | 4-8 |
| REP 3.3 | Scan Motor/Gear Assembl | 4-9 |
| REP 3.4 | Power Suppl | 4-10 |
| REP 3.5 | LIU PBA | |
| REP 3.6 | Parallel Cable Interface PBA | .4-12 |
| REP 4.1 | Printer Assembl | 4-14 |
| REP 4.2 | APF Tray Assembl | .4-15 |
| REP 4.3 | Maintenance Station | |
| REP 4.4 | Carriage Assembl | .4-17 |
| REP 4.5 | Main PBA | |
| REP 4.6 | Paper Guide Assembly | 4-19 |
| REP 4.7 | Roller Holder Assembly | .4-20 |
| REP 4.8 | Feed Roller | |
| REP 4.9 | Paper Feed Motor Assembl | .4-22 |
| ADJ 3.1 | Adjust CIS Shading | . 4.23 |
| ADJ 4.1 | Adjust Cartridge Alignment | .4-24 |

Introduction

Overview

The Repair/Adjustment section of the Service Manual provides information that enables the Service Representative to restore the product to within specifications after fault isolation.

The section contents lists, in sequence, all the items of the section, with page references. Each entry in the section contents appear exactly as it appears in the manual.

Repair Procedures

This repair subsection contains instructions for removal and replacement tasks. A removal and/or replacement task is included when it is not obvious how components are removed and replaced, or when special conditions (such as an adjustment) must be met during these tasks.

Step-by-step removal procedures for a specific component or assembly are provided.

Illustrations and photographs are used to assist you with the procedures. You should refer to the specific parts list illustration (listed under the repair title) for locating most components within a procedure.

REP 1.1 White Roller Assembly

Parts List: 1.1

Disconnect the power cord.




Removal

- 1. Open the control panel.
- 2. Push the bushing on both ends of the roller slightly inward, then rotate it until it reaches the slot as shown below. Then lift the roller out.

Note: Check the roller for any dirt. If dirty, wipe it off with soft cloth dampened with water or alcohol. If the roller is heavily worn, replace it with a new one.

Replacement

1. Reinstall the components in the reverse order



White Roller

REP 1.2 Rear Cover Assembly


Parts List: 1.1

Disconnect the power cord.




Removal


- 1. Disconnect the parallel cable and telephone lines.
- 2. Holding the paper guide, move it in the direction of arrow.



3. Remove the five screws shown below. Remove the screw and the storage unit on the WorkCentre 480.



4. Holding the rear cover assembly, remove it by rotating it up to be released properly.



Replacement

REP 1.3 Top Cover Assembly


Parts List: 1.1




Disconnect the power cord.

Removal

- 1. Open the control panel and open the ADF Door
- 2. Remove the White Roller Assembly (REP 1.1 White Roller Assembly)
- 3. Remove the Rear Cover Assembly (REP 1.2 Rear Cover Assembly).
- 4. Remove the nine screws shown below.



- Disconnect the Speaker harness (P5) from the Main PBA. On the WorkCentre 480 disconnect the ADF Door Interlock harness (P10) from the Main PBA.
- 6. Take off the Top Cover Assembly.



Replacement

REP 1.4 Control Panel Assembly


Parts List: 1.1


Disconnect the power cord.



Removal

- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Disconnect the control panel connector from the Main PBA.
- 3. Turn the ADF restraint 90 degrees as shown below and take off the Control Panel Assembly.





4. Remove the four screws securing the Control Panel Assembly to the Upper Scanner Assembly.

- 1. Install the Control Panel Assembly under the three tabs at front of control panel. Reinstall four screws.
- 2. Reinstall the components in the reverse order

REP 2.1 ADF Rubber Pad


Parts List: 2.1

Disconnect the power cord.




Removal

- 1. Open the Control Panel Assembly
- Insert a flat blade screw driver into the slot as shown below, and release the latches. Take out the Rubber Holder, ADF Sheet, and the Rubber Pad.



- 1. Reinstall the components in the reverse order, observing the following:
 - When you reassemble the Rubber Pad, be sure that the Rubber Pad, ADF Sheet and Rubber Holder fit into the Guide Boss and the Rubber Holder latches fit into the corresponding holes. Push firmly until both latches click.
 - Clean the surface of the Rubber Pad with alcohol.
 Check the Rubber Pad for wear. If the wear reaches 1/2 the original thickness, replace it with a new one.





REP 3.1 Rollers (ADF and Drive) and Document Exit Shaft Assemblies


Parts List: 3.1

Disconnect the power cord.



Removal

- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Remove the rollers from the base assembly.



Replacement

1. Reinstall the components in the reverse order

Note: Before replacing the components, clean the surface of the rollers with alcohol. After wiping them, you must dry them completely.

REP 3.2 CIS (Contact Image Sensor)


Parts List: 3.1

Disconnect the power cord.




Removal

- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Remove the Drive Roller shown below.
- 3. Remove the screw securing the CIS Assembly.
- 4. Disconnect the CIS Harness. Remove the CIS Assembly.
- 5. Remove the one screw from the bottom of the CIS Assembly to release the CIS from the bracket.



Note: Be careful not to lose the springs.

Note: Check the glass surface of the CIS for any stain or scratches. If stained, wipe off with alcohol. If it is heavily stained or scratched, replace it with a new one.



Replacement

Note: Insure that the CIS Bracket remains around the locating posts during insertion of screw. Push down on CIS to make sure it is free after inserting screw. If White Roller is difficult to install check the CIS for proper replacement.

- 1. Reinstall the components in the reverse order
- 2. Perform Adj 3.1 Adjust CIS Shading.

REP 3.3 Scan Motor/Gear Assembly


Parts List: 3.1

Disconnect the power cord.




Removal

- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Disconnect motor connector P2 from the Main PBA. Make sure the harness is released from the hooks securing the harness as shown below.



3. Remove the two screws as shown below and take out the Scan Motor/Gear Assembly.



4. Disconnect the ground wire from the right side of the Main Frame.

Replacement

REP 3.4 Power Supply


Parts List: 3.1

Disconnect the power cord.




Removal


- 1. Remove the Rear Cover Assembly (REP 1.2 Rear Cover Assembly).
- 2. Disconnect the Power Supply connector P6 from the Main PBA. Make sure the harness is released from the hooks.




3. Remove the screw securing the ground wires to the bracket as shown.



4. Remove the screw securing the ground wire to the Main Frame as shown. Make sure the harness is released from the hook.



5. Pushing down the hooks on both ends, pull out the Power Supply.



Replacement

1. Reinstall the components in the reverse order.

REP 3.5 LIU PBA


Parts List: 3.1

Disconnect the power cord.




Removal


- 1. Remove the Rear Cover Assembly (REP 1.2 Rear Cover Assembly).
- 2. Remove the screw securing the ground wires to the left rear side of the Main Frame.
- 3. Disconnect the LIU PBA connector P7 from the Main PBA.



4. While pulling the latching snaps locking the PBA outward, push the LIU PBA up to remove.



5. Disconnect the remaining connectors from the LIU PBA.



Replacement

1. Reinstall the components in the reverse order.

REP 3.6 Parallel Cable Interface PBA


Parts List: 3.1



Disconnect the power cord.

Removal

- 1. Remove the Rear Cover Assembly (REP 1.2 Rear Cover Assembly).
- 2. Disconnect Parallel Interface connector CN1 from the Main PBA.
- 3. Remove screw securing the ground wires to the end of the Main Frame.
- 4. Remove screw and remove the Parallel Cable Interface PBA.



Replacement

REP 4.1 Printer Assembly

Parts List: 4.1

Disconnect the power cord.




Removal


- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Remove the three screws securing the printer Assembly.
- 3. Disconnect the Control Panel, LIU, CIS, Power Supply, Scan Motor and Parallel Interface PBA connectors from the Main PBA.
- 4. Disconnect the ground wire at the right end of the Printer Assembly next to the Carriage Motor.
- 5. Disconnect the ground wire at the left end of the Printer Assembly next to the Paper Feed motor.
- 6. Remove the Printer Assembly.

Replacement

1. Reinstall the components in the reverse order. Be sure to install the Main Frame under the two tabs on the Base Assembly.

Note: When you reassemble the unit, do not pinch or short the wire harnesses.





REP 4.2 APF Tray Assembly


Parts List: 4.1

Disconnect the power cord.




Removal

- 1. Remove the Rear Cover Assembly (REP 1.2 Rear Cover Assembly).
- 2. Disconnect P4 and P8 (480 only) connectors from the Main PBA.
 - 3. Remove the three screws shown below.



- 4. Remove the APF Tray Assembly (REP 4.2) from the printer unit by pushing the feeder in, down and slightly to the left until it can be removed.
- 5. Remove the APF Tray Assembly out in the direction of arrow.



APF Tray Assembly

Replacement

REP 4.3 Maintenance Station


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the Printer Assembly (REP 4.1 Printer Assembly).
- 2. Center the Carriage Assembly to the left off of the Home Assembly.
- 3. Release the locking tabs at both ends of the Maintenance Station on the Main PBA side of the Main Frame. Remove the Maintenance Station in the direction of the arrow.



4. Gently push the locating pins to remove the Maintenance Station. Hold the seals and tabs to the right so they will not hit the Paper Guide during removal.

Replacement

Note: When inserting Maintenance Station into position, be careful that the pins are pushed into the locating holes.

REP 4.4 Carriage Assembly


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the Printer Assembly (REP 4.1 Printer Assembly).
- 2. Center the Carriage Assembly.
- 3. Disconnect JP1, JP2, and JP3 from the Main PBA.
- Remove the Springs located at both ends of the Carriage Shaft.
- 5. Remove the Carriage Shaft.
- Remove the screw on the left side of the Carriage Motor. Then
 loosen the screw on the right side of the Carriage Motor so that the
 Carriage Drive Belt can be removed from the Carriage Motor and
 Pulley.
- 7. Gently lift up to release the tabs on top of the Carriage from the top of the Main Frame and the Encoder Sensor form the Encoder
- 8. Remove the Carriage Assembly from the Main Frame.
- Make a note of how and where the Carriage Assembly is connected to the Carriage Drive Belt for future reference when replacing the Carriage Assembly.



- 1. Reinstall the components in the reverse order
- 2. When completed, loosen the screw holding the Carriage Idler Pulley Holder to allow the spring to tighten the belt properly.

REP 4.5 Main PBA


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the Top Cover Assembly (REP 1.3 Top Cover Assembly).
- 2. Disconnect all connectors from the Main PBA.
- 3. Remove one screw securing the Main PBA at the right edge of the PBA (when viewed from the rear).
- 4. Pull the sensor lever towards the rear, then remove the Main PBA by lifting the top right corner



- 1. Reinstall the components in the reverse order
- 2. Perform Adj. 3.1 Adjust CIS Shading.

REP 4.6 Paper Guide Assembly


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the following:
 - a. Roller Holder Assembly (REP 4.7 Roller Holder Assembly).
 - b. Carriage Assembly (REP 4.4 Carriage Assembly).
 - c. Maintenance Station (REP 4.3 Maintenance Station)
- 2. Remove the two screws securing the Exit Roller Assembly to the Paper Guide.
- 3. Remove the Exit Roller by gently pulling on the right end to free the roller.
- 4. Remove the Exit Roller from the Drive Belt.
- 5. Gently remove the right side of the Paper Guide from the Main Frame while removing it from the Feed Roller
- 6. Remove the left side of the Paper Guide from the Main Frame while removing it from the Feed Roller in the direction shown below.



- 1. Remove the Exit Roller Gear at the left end of the Exit Roller for easier replacement. The gear end is inserted into the roller.
- 2. Reinstall the components in the reverse order

REP 4.7 Roller Holder Assembly

Parts List: 4.1


Disconnect the power cord.



Removal

- 1. Remove the following:
 - a. Top Cover Assembly (REP 1.3 Top Cover Assembly)
 - b. Printer Assembly (REP 4.1 Printer Assembly).
 - c. APF Tray Assembly (REP 4.2 APF Tray Assembly).
 - d. Main PBA (REP 4.5 Main PBA).
- 2. Disconnect four Friction Springs from four Friction Holders to the Roller Holder.
- Depress the two latching tabs on the Roller Holder on the front side of the Main Frame. Slide the Roller Holder down as shown to remove.

Replacement



REP 4.8 Feed Roller


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the Paper Guide Assembly (REP 4.6 Paper Guide Assembly).
- 2. Remove the Right Feed Bearing as shown below.



3. Pull the Feed Roller in the direction of the arrow and take it out.

Replacement

REP 4.9 Paper Feed Motor Assembly


Parts List: 4.1

Disconnect the power cord.



Removal

- 1. Remove the Feed Roller (REP 4.8 Feed Roller).
- 2. Remove the two screws and take out the Paper Feed Motor Assembly.



Replacement

ADJ 3.1 Adjust CIS Shading

This procedure is used to adjust the amount of light for the CIS.

WARNING

CIS Shading MUST be performed after downloading a new firmware version. If not, the system will not work properly.

Note: Clean the CIS, Platen Glass and White Roller before performing this adjustment.

ADJUST SEQUENCES

- 1. Load an all white document in scanner Unit.
- 2. Press 🗐 , #, 1, 9, 3, 4.
- 4. LCD will display "CIS SHADING?".
- 5. Press \$\triangle\$ then LCD will display "SHADING...".
- 6. After scanning, a shading waveform will be printed out.
- 7. Press ① .
- 8. Turn OFF system, then Turn IT ON to complete setting.

ADJ 4.1 Adjust Cartridge Alignment

This procedure is used to arrange the alignment of the Black, Color and Photo Cartridge. When a color and a black cartridge is installed you get four settings, A, B, C, & D. When you have a color and a photo cartridge installed you get only adjustment A & B for the new cartridge.

ADJUST SEQUENCES

- 1. Press ≡ , 013 (Maintenance), ∨.
- 2. LCD will display "ARRANGE ALIGNMENT?".
- 3. Press igoplus then LCD will display "PRINTING...".
- 4. After printing the "CARTRIDGE ALIGNMENT" selection sheet, select the number in each section that represents the proper alignment such as; for "ALIGNMENT A" number 5 is the best setting for the vertical line and "ALIGNMENT B" number 7 is the best setting for the horizontal line.
- 5. Enter the number of your selection when it is requested on the machine display, then press \diamondsuit to go to the next selection.
- When all selections have been made the machine returns to standby.



Section Contents

| Title | Page |
|------------------------------|--------|
| Introduction | 5-1 |
| PL 1.1 Main Assembly | 5-2 |
| PL 2.1 Control Panel Assembl | 5-5 |
| PL 3.1 Base Assembl | 5-6 |
| PL 4.1 Engine & APF Assembly | 5-8 |
| Part NO. Index | - 5-10 |
| | |

Introduction

Overview

The Parts Lists section provides exploded view illustrations of all spared subsystem components and a listing of the corresponding part numbers. The illustrations show the relationships between parts.

Organization of this Section

The following elements make up the Parts List section:

Parts Lists (PL)

Each item number in the part numbers listing corresponds an item number in the illustration. All the parts in a given subsystem of the machine will be located in the same illustration or in a series of associated illustrations. The parts which are not spared are indicated by "--" in the Part column.

Exploded View Illustrations


An item that is called out on an illustration has a corresponding listing withinhtis section.

Components are given item numbers that correspond to the part number listings.

Part Number Index

This inde x lists all the spared parts in the system in numerical order. Each number is followed by a reference to the parts list on which the part may be found.

PL 1.1 Main Assembly




PL 1.1 Main Assembly

| Item | Part | Description |
|------|-----------|------------------------------------------------|
| 1. | | Control Panel Assembly (See PL 2.1) (REF only) |
| 2. | | Document Input Tray Base |
| 3. | | Document Input Tray Extension |
| 4. | 060K01530 | Cartridge Storage Assembly (480 only) |
| ı | 002N01646 | Cartridge Storage Cover (470 only) |
| 5. | 002N01622 | Rear Cover |
| 6. | | Base Assembly (See PL 3.1) (REF only) |
| 7. | 050N00281 | Document Exit Tray Extension (480) |
| 1 | 050N00290 | Document Exit Tray Extension (470) |
| 8. | -,- | Engine Assembly (See PL 4.1) (REF only) |
| 9. | 002N01623 | Top Cover Assembly (US/XE) |
| 1 | 002N01627 | Top Cover Assembly (ACO) |
| 10. | 022K64470 | White Roller Assembly |
| 11. | 110K10140 | Handset (ACO only) (Not shown) |
| 12. | 117K32600 | Handset Cord (ACO only) (Not shown) |
| 13. | 117K13660 | Power Cord (Not show |
| 14. | 140N05292 | Hook PBA (ACO) (Not shown) |
| 15. | 152N01682 | Hook, Harness (ACO) (Not shown) |
| 16. | 162K06530 | RTI Cable (Not shown) |
| 17. | 162K39580 | Printer Cable (Not shown) |
| 18. | 050N00297 | Document Exit Tray Base (480) |
| | 050N00291 | Document Exit Tray Base (470) |
| 19. | 600N01590 | Hardware Kit |
| 20. | 050N00280 | Document Input Tray Assembl |
| 21. | 050N00279 | Printer Exit Tray Assembl |

PL 2.1 Control Panel Assembly

1 3{1,8,A&D 4{5,6,7,D 10{A&D




PL 2.1 Control Panel Assembly

| | Item | Part | Description |
|---|------|--------------------|----------------------------------------------|
| | 1. | 802E17830 | One-Touch Cover |
| | 2. | 092P42302 | Control Panel Overlay, (Dutch) |
| | | 092P42309 | Control Panel Overlay, (French) |
| | | 092P42300 | Control Panel Overlay, (German) |
| | | 092P42303 | Control Panel Overlay, (Italian) |
| | | 092P42312 | Control Panel Overlay, (Portuguese) |
| | | 092P42313 | Control Panel Overlay, (Spanish) |
| ĺ | 3. | 101N01177 | Control Panel Assembly (480 only) (See Note) |
| | | 101N01184 | Control Panel Assembly (470 only) (See Note) |
| | 4. | 101N01178 | Upper Scanner Assembly |
| | 5. | | ADF Sheet (REF only) |
| | 6. | 019E43540 | ADF Rubber Holder |
| | 7. | 019E43530 | ADF Rubber |
| | 8. | 891E99030 | One-Touch Label, (Dutch) |
| | | 891E88990 | One-Touch Label, (English) |
| | | 891E99060 | One-Touch Label, (French) |
| | | 891E99010 | One-Touch Label, (German) |
| | | 891E99040 | One-Touch Label, (Italian) |
| I | | 891E99080 | One-Touch Label, (Portuguese) |
| ı | | 891E99070 | One-Touch Label, (Spanish) |
| ı | 9. | 892E14630 | Menu Overlay, (Dutch) |
| ı | | 892E14250 | Menu Overlay, (French) |
| ı | | 892E14620 | Menu Overlay, (German) |
| I | | 892E14640 | Menu Overlay, (Italian) |
| ı | | 892E14610 | Menu Overlay, (Portuguese) |
| I | | 892E14600 | Menu Overlay, (Spanish) |
| • | 10. | 600 N 01590 | Hardware Kit |
| | | | |

Note: When ordering item 3, also order items 2, 8, and 9 with the proper languages.


PL 3.1 Base Assembly



PL 3.1 Base Assembly

| | Item | Part | Description |
|---|------|-----------|-------------------------------------|
| | 1. | 105N01268 | Power Supply Assembly (110V - 220V) |
| | 2. | 022K64490 | ADF Roller Assembl |
| | 3. | 013N00392 | Bushing |
| ı | 4. | 152N01671 | LIU Harness (XE) |
| I | | 152N01672 | LIU Harness (USO/XCL/ACO) |
| | 5. | 140N05254 | Parallel Interface PBA |
| | 6. | 030N00434 | ADF Spring Clips |
| | 7. | 002N01624 | Base Cover Assembl |
| | 8. | 019N00435 | Felt Pad |
| | 9. | 127K30440 | Scan Motor/Gear Assembl |
| I | 10. | | Deleted |
| ı | 11. | | Deleted |
| | 12. | | Deleted |
| | 13. | 017N00167 | Rubber Foot |
| | 14. | 830E28530 | ADF Restraint |
| | 15. | 006E67100 | Document Exit Shaft Assembly |
| ı | 16. | 809E23900 | Ground Spring Plate |
| | 17. | 809E23890 | CIS Spring |
| | 18. | 830E40000 | CIS Bracket |
| | 19. | 109K01250 | CIS |
| | 20. | 152N01670 | CIS Harness |
| | 21. | 162K51140 | CIS Harness GND |
| | 22. | 022K64480 | Scan Drive Roller Assembly |
| I | 23. | 140N05313 | LIU PBA (USO/XCL) (470) |
| | | 140N05328 | LIU PBA (XE) (470) |
| | | 140N05403 | LIU PBA (ACO) (470) |
| | | 160K64040 | LIU PBA (USO/XCL) (480) |
| | | 160K64850 | LIU PBA (XE) (480) |
| 1 | | 160K64860 | LIU PBA (ACO) (480) |
| | 24. | 600N01590 | Hardware Kit |

PL 4.1 Engine & APF Assembly



PL 4.1 Engine & APF Assembly

| Item | Part | Description |
|-------|--------------------|-------------------------------------------|
| 1. | 022N01026 | APF Tray Assembly (480, Alternate to 470) |
| | 022N01042 | APF Tray Assembly (470 only) |
| 2. | 127N01011 | Carriage Motor Assembly |
| 3. | 001N00298 | Main Frame Assembl |
| 4. | 013E14870 | Right Feed Bearing |
| 5. | 094N00210 | Maintenance Station |
| 6. | 022N01027 | Feed Roller |
| 7. | 001N00297 | Paper Guide |
| 8. | 041N00198 | Carriage Assembly |
| 9. | 006E66200 | Carriage Shaft |
| 10. | 009 N 01070 | Carriage Shaft Spring |
| _ 11. | 146N00095 | Encoder |
| 12. | 020N00470 | Idler Pulley Assembly |
| 13. | 030N00433 | Paper Feed Motor Assembl |
| 14. | 140N05255 | Main PBA (480 only) |
| | 140N05312 | Main PBA (470 only) |
| 15. | 022N01028 | Roller Holder Assembly |
| 16. | 600N01590 | Hardware Kit |
| 17. | 050N00282 | Guide Extension |

Part NO. Index

| Part Number | PL | Part Number | PL | Part Number PL | |
|-------------|-----|-------------|-----|-----------------------------------------------|----------|
| 001N00297 | 4.1 | 092P42303 | 2.1 | 802E17830 2.1 | |
| 001N00298 | 4.1 | 092P42309 | 2.1 | 809E23890 3.1 | |
| 002N01622 | 1.1 | 092P42312 | 2.1 | 809E23900 3.1 | |
| 002N01623 | 1.1 | 092P42313 | 2.1 | 830E28530 3.1 | |
| 002N01624 | 3.1 | 094N00210 | 4.1 | 830E40000 3.1 | |
| 002N01627 | 1.1 | 101N01177 | 2.1 | 891E88990 2.1 | |
| 002N01646 | 1.1 | 101N01178 | 2.1 | 891E99010 2.1 | |
| 006E66200 | 4.1 | 101N01184 | 2.1 | 891E99030 2.1 | |
| 006E67100 | 3.1 | 105N01268 | 3.1 | 891E99040 2.1 | |
| 009N01070 | 4.1 | 109K01250 | 3.1 | 891E99060 2.1 | |
| 013E14870 | 4.1 | 110K10140 | 1.1 | 891E99070 2.1 | |
| 013N00392 | 3.1 | 117K13660 | 1.1 | 891E99080 2.1 | |
| 017N00167 | 3.1 | 117K32600 | 1.1 | 892E14250 2.1 | |
| 019E43530 | 2.1 | 127K30440 | 3.1 | 892E14600 2.1 | |
| 019E43540 | 2.1 | 127N01011 | 4.1 | 892E14610 2.1 | |
| 019N00435 | 3.1 | 140N05254 | 3.1 | 892E14620 2.1 | |
| 020N00470 | 4.1 | 140N05255 | 4.1 | 892E14630 2.1 | |
| 022K64470 | 1.1 | 140N05292 | 1.1 | 892E14640 2.1 | |
| 022K64480 | 3.1 | 140N05312 | 4.1 | 552214646 | |
| 022K64490 | 3.1 | 140N05313 | 3.1 | | |
| 022N01026 | 4.1 | 140N05328 | 3.1 | Common Hardware Kit | |
| 022N01027 | 4.1 | 140N05403 | 3.1 | Description | Qty. |
| 022N01028 | 4.1 | 146N00095 | 4.1 | • | - |
| 022N01042 | 4.1 | 152N01670 | 3.1 | A. Tapping Screw 2.5 x 6 | 10 |
| 030N00433 | 4.1 | 152N01671 | 3.1 | B. Tapping Screw 3 x 5 | 10 10 |
| 030N00434 | 3.1 | 152N01672 | 3.1 | C. Tapping Screw 3 x 6 D. Tapping Screw 3 x 8 | 10 |
| 041N00198 | 4.1 | 152N01682 | 1.1 | E. Tapping Screw 3 x 10 | 10 |
| 050N00279 | 1.1 | 160K64040 | 3.1 | an inspiring content of the | |
| 050N00280 | 1.1 | 160K64850 | 3.1 | | |
| 050N00281 | 1.1 | 160K64860 | 3.1 | | |
| 050N00282 | 4.1 | 162K06530 | 1.1 | | |
| 050N00290 | 1.1 | 162K39580 | 1.1 | | |
| 050N00291 | 1.1 | 162K51140 | 3.1 | | |
| 050N00297 | 1.1 | 600N01590 | 1.1 | | |
| 060K01530 | 1.1 | 600N01590 | 2.1 | | |
| 092P42300 | 2.1 | 600N01590 | 3.1 | | |
| 092P42302 | 2.1 | 600N01590 | 4.1 | | |

6. General Procedures/Information

Section Contents

| Title | Page |
|-----------------------------------|--------|
| Introduction | 6-1 |
| Precautions | 6-2 |
| Product Codes | 6-2 |
| Using the Control Panel | 6-3 |
| WorkCentre 480/470cx Differences | 6-4 |
| Accessories/Supplies/Consumables | |
| Specifications | 6-6 |
| Printer Engine | 6-6 |
| Head | 6-6 |
| Power & Size | 6-6 |
| Scanner | 6-6 |
| Facsimile | 6-7 |
| XE LIU PBA Country Configurations | 6-9 |
| List Abbreviations | - 6-10 |
| Service Mode | 6-11 |
| Maintenance | 6-11 |
| Setting Up the System | - 6-12 |
| Changing System Setup | - 6-12 |
| System Setup Options | - 6-12 |
| System Data | - 6-14 |
| Changing System Data | - 6-14 |
| Selectable System Data | - 6-14 |
| Firmware Matrix | - 6-15 |
| Modifications | - 6-18 |
| Installation | |

Introduction

This section includes the precautions and machine specifications. Also included is a list of abbreviations used throughout the manual.

Precautions

Follow these safety, ESD, and servicing precautions to prevent personal injury and equipment damage.

- Be sure that all built-in protective devices are in place. Restore any missing protective shields.
- Make sure there are no cabinet openings through which people- particularly childrenmight insert fingers or objects and contact dangerous voltages.
- When re-installing chassis and assemblies, be sure to restore all protective devices, including control knobs and compartment covers.
- Design Alteration Warning: Never alter or add to the mechanical or electrical design of this equipment, such as auxiliary connectors, etc. Such alterations and modifications will void the manufacturer's warranty.
- Components, parts, and wiring that appear to have overheated or are otherwise damaged should be replaced with parts which meet the original specifications. Always determine the cause of damage or overheating, and correct any potential hazards.
- Observe the original lead dress, especially near sharp edges, AC, and high voltage power supplies. Always inspect for pinched, out-of-place, or frayed wiring. Do not change the spacing between components and the printed circuit board.
- 7. Product Safety Notice:
 Some electrical and mechanical parts have special safety-related characteristics which might not be obvious from visual inspection.
 These safety features and the protection they provide could be lost if a replacement

component differs from the original. This holds true, even though the replacement may be rated for higher voltage, wattage, etc.

Components critical for safety are indicated in the parts list. Use only replacement components that have the same ratings, especially for flame resistance and dielectric specifications. A replacement part that does not have the same safety characteristics as the original may create shock, fire, or other safety hazards.

ESD Precautions

Certain semiconductor devices can be easily damaged by static electricity. Such components are commonly called "Electrostatically Sensitive (ES) Devices", or ESDs. Examples of typical ESDs are: integrated circuits, some field effect transistors, and semiconductor "chip" components.

The techniques outlined below should be followed to help reduce the incidence of component damage caused by static electricity.

CAUTION:

Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

- Immediately before handling a semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, employ a commercially available wrist strap device, which should be removed for your personal safety reasons prior to applying power to the unit under test.
- After removing an electrical assembly equipped with ESDs, place the assembly on a conductive surface, such as aluminum or


- copper foil, or conductive foam, to prevent electrostatic charge buildup in the vicinity of the assembly.
- Do not use Freon-propelled chemicals. When sprayed, these can generate electrical charges sufficient to damage ESDs.
- 4. Do not remove a replacement ESD from its protective packaging until immediately before installing it. Most replacement ESDs are packaged with all leads shorted together by conductive foam, aluminum foil, or a comparable conductive material.
- Immediately before removing the protective shorting material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
- Maintain continuous electrical contact between the ESD and the assembly into which it will be installed, until completely plugged or soldered into the circuit.
- Minimize bodily motions when handling unpackaged replacement ESDs. Normal motions, such as the brushing together of clothing fabric and lifting ones foot from a carpeted floor, can generate static electricity sufficient to damage an ESD.

Product Codes

| Country | 480 Code | 470 Code |
|----------|----------|----------|
| USO/XCL | KU3 | MC7 |
| XBRA/XLA | KU4 | MC8 |
| XE | KU5 | MC9 |

Using the Control Panel

Shown below are the controls used to operate the printer.All the controls are located on the front Control Panel.



WorkCentre 480/470cx Differences

The WorkCentre 480cx and WorkCentre 470cx are basically the same machine. There are a few hardware and firmware differences between the two machines which will be call out here and in the "Using the Control Panel" section on the previous page.

To understand the differences it is recommended that you review:

- · Using the Control Panel
- · Accessories/Supplies/Consumables
- Specifications
- · Service Mode
 - Maintenance
- Setting Up the System
 - System Setup Options
- System Data
 - · Selectable System Data

Summary of 480cx to 470cx Differences

| Description | 480cx | 470cx |
|------------------------|-----------|---------------|
| Print speed (mono) | 8PPM | 6РРМ |
| Image Memory | 2.5 Meg | 0.5meg |
| Battery Backup | 1 Hour | 15 Minutes |
| Quick-Scan speed | 3 Seconds | 6 Seconds |
| PC Fax | Supported | Not Supported |
| LaserFax Lite | Provided | Not Provided |
| MGI Photo Suite | Provided | Not Provided |
| APF Paper Empty Sensor | Provided | Not Provided |
| ADF Door Interlock | Provided | Not Provided |
| Ink Cartridge Storage | Provided | Not Provided |

- Express Button changed to Cartridge Center Button on the Control Panel.
- Initial supply of the Black Ink Cartridge is standard capacity.
- Some cosmetic (color) changes to trays and guides.

Accessories/Supplies/Consumables

| Bundle S/W | USO/XCL English/French | XBRA/XLA Portuguese/Spanish | XE |
|---------------------------------------------------------------------------|---------------------------|--------------------------------|-----------------|
| 2 CD Roms: | | | |
| #1 - Pagis Pro 2.0, LaserFax (480 only), | 300N01777 (480) | 300N01739 (480) | 300N01739 (480) |
| Adobe Acrobat Reader, Printer, Scanner and Fax Drivers, Online User Guide | 300N01847 (470) | 300N01848 (470) | 300N01848 (470) |
| #2 - Software MGI PhotoSuite (480 only) | 300N01734 (480) | 300N01734 (480) | 300N01734 (480) |
| Accessories | | | |
| Parallel Cable | 162K39580 | 162K39580 | 162K39580 |
| Supplies | | | |
| Ink Cartridge | Black - 8R7881 | Black - 8R7881 | Black - 8R7881 |
| • | Color - 8R7880 | Color - 8R7880 | Color - 8R7880 |
| | Photo - 8R7883 | Photo - 8R7883 | Photo - 8R7883 |
| Lint Free Tissue | 35P2163 | 035P02163 | 600S04372 |
| Lubricant | 70H44 | 70H44 | TBD |
| CLEAN-UPS | 43P67 | 43P67 | 43P67 |
| Film Remover | 43P45 | 43P45 | 8R90020 |
| Lens Cleaner | 43H12 | 43H12 | 600T90318 |
| Paper Towels | 35P3191 | 35P3191 | 8R90019 |
| Test Pattern | 82P151 | 82P151 | 82P151 |

Specifications

Table 6-1. Printer Engine

| | | , |
|----------------------------------------------------|-------------------------|--------------------------------------------------------------------------------------|
| Technolog | | Thermal Inkjet 2-pen & Print Head Swapping Type |
| Speed | Color (*1) Mono (*2) | 3ppm at Draft Mode 8ppm at Draft Mode (480 only) 6ppm at Draft Mode (470 only) |
| Resolution | Color | 600 x 600 dpi (1200 x 1200 dpi Addressable) |
| | Mono | 600 x 600 dpi (1200 x 1200 dpi Addressable) |
| Printing Width | | 203mm |
| Feeding Method | Automatic Manual | 100 Sheets of 20lb cut sheets Yes |
| Emulation | | Host Based Printing (GDI) |
| Printer Driver | | Windows 3.1/3.11, Windows 95/98 driver, Windows NT4.0 |
| Interface | | IEEE 1284 Compatible Parallel Interface (ECP) |
| (*1) The average print time with 15%/A4 test image | | |

^(*1) The average print time with 15%/A4 test image.

Table 6-2. Head

| | Mono (Black) | Color |
|------------|----------------------------------------|----------------------------------------|
| Print Head | 208 nozzles | 192 nozzles |
| Ink type | Pigment | Dye |
| Ink Yield | about 1075 sheets at 5% image coverage | about 240 sheets at 15% image coverage |

Table 6-3. Power & Size

| Power | 90 to 265 Volts AC 50/60 HZ Standby: 30 Watts Minimum Operating: 300 Watts Maximum |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Dimensions (W x D x H) | 438mm x 360mm x 192mm (Without Handset) 17.2" x 14.2" x 7.6" (Without Handset) |
| Weight | 6.3Kg (14lb) Unpackaged 10.5Kg (23lb) Packaged |
| Operating Environment | Temperature: 10 to 32.5C (50 to 104 F) degrees Relative Humidity: 20 to 80% Altitude: up to 2500 meters (8,250 feet) |
| ЕМЕ | FCC Part 15 Class B EN 60950 EN 55022 EN 50082 |

Table 6-4. Scanner

| Compatibility | TWAIN |
|----------------------------|-------------------------------|
| Technology | CIS |
| Light Source for Color CIS | RGB LEDs (Line Order Control) |

^(*2) The average print time with 4%/A4 test image.

Table 6-5. Facsimile

| General | Compatibility | ITU-G3 | | |
|----------|--------------------|---------------------------------------|--|--|
| | Scan method | CIS | | |
| | Scan width | Max. 216mm, Effective: 210mm | | |
| | Scan Resolution | 300 x 300 dpi | | |
| | Scan Speed | 3 sec | | |
| | Feeding method | Sheet | | |
| | ADF | 30 sheets of 20lbs | | |
| | Document Trays | Input and Exit | | |
| | Paper Tra | APF (With Manual Tray) | | |
| | Modem Speed | 14.4 Kbps | | |
| | Coding Method | MH, MR, MMR, Error Correction Mode | | |
| | LCD | 2 Lines Each of 16 Characters | | |
| Scanning | Resolution | Standard: 200 x 100 dpi | | |
| | | Fine: 200 x 200 dpi (Default) | | |
| | | Superfine: 300 x 300 dpi | | |
| | Gray Scale & | Darken | | |
| | Contrast | Lighten | | |
| | egetono. | Photo: Error diffusion | | |

Table 6-5. Facsimile - continued

| Table 0-3. Facsimile Continued | | | | |
|--------------------------------|-------------------------|--------------------------------------------------------|--|--|
| Memory | Capacity | 2.5 Mbyte (480 only) 0.5 Mbyte (470 only) | | |
| | Back-up Time | 30 Minutes (Continuous Power Failure) (3 Volt Lithium) | | |
| | Confidential | No | | |
| | Delayed | Up to 10 Locations | | |
| | Group Dial | 20 Number Programmable | | |
| | Forced Memory Tx. | Yes | | |
| • | Priority Tx. | Yes | | |
| | Memory | Automatic reception when paper empty. | | |
| | Confidential | No | | |
| Telephone | One-touch Dial | 20 Locations | | |
| | Speed Dial | 50 Locations | | |
| | Chain Dial | Yes | | |
| | Handset & Cradle | South America Onl | | |
| | On-hook Dial | Yes, 1-Ke | | |
| | Last Number Redial | Yes, 1-Ke | | |
| | Auto Busy Redial | Yes | | |
| | No Power Opera- tion | UK : CALLING only, Other Country : No | | |
| | Hold & Mute | No | | |
| | Pause | Yes, Use Redial Key | | |
| | Ringer Volume | S/W Option Setting (4Steps) | | |
| | Tone/pulse Select | S/W Option setting | | |
| | Flash | Yes | | |
| | DRPD | US : Yes, Other Country : No | | |

Table 6-5. Facsimile - continued

| Reports & List | TX/RX Journal | Yes | |
|-------------------|-------------------------|-------------------------------------------------------|--|
| | Image TCR | Yes, Reduction of First Page Sent by Memory Tx | |
| | Delayed Dial List | Yes | |
| | System Data | Yes | |
| | Tel Number List | Yes | |
| | Help List | Yes | |
| Сору | Multi-page Copy | Up to 99 Pages | |
| | Gray Scale | 256 Levels | |
| | Reduction & Enlargement | 25%~200% (Reference is the top center of Document) | |
| Tel I/F | Answering I/F | Yes | |
| | Ext. Phone | 1-jack, Extension Phone Transfer | |
| Others | Polling | Yes | |
| | Sensors | No Paper (480 only), Paper Jam, Scan Position | |
| | Error Indicator | 1-LED, 2-LCD Display | |
| | Real Time Clock | Yes | |
| | RTI | Yes | |

| XE LIU PBA Country Configurations

Jumper Settings

See LIU component layout for jumper positions and pin callouts.

| Country | P2 (DP Ratio) | P4 (DCR) | P5 (Impedance) |
|-------------------------------------------------------------------------------------------|---------------------|--------------|-------------------|
| Austria Denmark Finland France Germany Greece Italy Netherlands Norway Sweden Switzerland | 40 to DP | CTR21 to DCR | CTR21 to IMP |
| Belgium Portugal Spain U.K. | 33 to DP | CTR21 to DCR | CTR21 to IMP |
| Bulgaria Czech Romania Russia Turkey Ukraine Yugoslavia | 40 to DP | DCR to OTHER | No Setting |
| Hungary Poland | 33 to DP | DCR to OTHER | No Setting |

List Abbreviations

| Acronym | Definition |
|---------|---------------------------------------------|
| MFP | Multi Function Peripheral |
| I/F | Interface |
| UART | Universal Asynchronous Receiver/Transmitter |
| ECP | Extended Capabilities Port |
| CR | Carriage Return |
| LF | Line Feed |
| SCANIP | SCAN Image Processor |
| CIS | Contact Image Sensor |
| A/D | Analog To Digital |
| D/A | Digital To Analog |
| LIU | Line Interface Unit |
| TIT | Transformer Input From Transformer |
| ROT | Receive Output Transformer |
| LI | Line Input |

Service Mode

6-1-1-1 HOW TO ENTER SERVICE MODE

In service mode (tech) mode, the technician can check the machine and perform various test to isolate the cause of a malfunction.

To enter the service mode press \equiv , #, 1, 9, 3, 4 in sequence. The LCD displays "T", indicating the machine has entered service (tech) mode. While in service mode, the machine still performs all normal operations. To return to normal user mode, press \equiv , #, 1, 9, 3, 4 in sequence again.

Options changed while in service mode do not remain changed unless you clear the machines memory.

Maintenance

To enter Service Mode press \equiv , #, 1, 9, 3, 4 before pressing \equiv and one-touch button 13, Maintenance. Press \land or \lor repeatedly to select the desired option.

When the desired option appears, enter the corresponding information to change the status of the selected function. Press (to return to the standby display.

| User Mode | Test |
|--------------------------------------|-----------------------------------------------------------------------------------------|
| SELF TEST | Performs a print out demonstrating print quality. Date on printout is F/W version date. |
| ARRANGE ALIGNMENT | Allows alignment of the partridge printing Heads. |
| CLEAN HEAD | Cleans the head to improve quality. |
| ADJUST SHADING | Adjusts CIS white reference point. |
| Service Mode | Report |
| SYSTEM DATA REPORT | System Data settings are reported. |
| SCHEDULE JOB REPORT | Jobs scheduled are listed. |
| PHONE BOOK REPORT | Telephone listing of numbers in memory. |
| MESSAGE CONFIRMIRMATION REPORT | Report showing confirmation of last message sent. |
| TRANSMISSION REPORT | Transmission Journal listing of jobs sent. |
| RECEPTION REPORT | Reception Journal listing of jobs received. |
| PROTOCOL REPORT | Listing of the signals sent and received during the last facsimile operation. |

| HELP LIST REPORT | Provides a menu listing of all items that can be accessed and the button to press for their access. |
|---------------------|-----------------------------------------------------------------------------------------------------------------------|
| SELF TEST REPORT | Self Test print out showing quality of print. |
| CIS SHADING PATTERN | Print out showing the last test after accomplishing a Shading adjustment. |
| ASF TEST | Provides continuous feeding of paper from the ASF with each page numbered at the top right corner until (is pressed. |
| NVRAM DUMP REPORT | Gives dot count varibles for cartridges installed. |

Setting Up the System

Changing System Setup

To enter Service Mode press \equiv , #, 1, 9, 3, 4 before pressing \equiv and one-touch button 04, System Setup. Press \land or \lor repeatedly to select the desired option.

When the desired option appears, enter the corresponding information to change the status of the selected function. Press (to return to the standby display.

System Setup Options

| User Mode | Item | Default Status |
|-----------------|----------------------------------------------------------------------------------------------------------------|-------------------|
| RINGER VOLUME | [OFF/LOW/MEDIUM/HIGH] | HIGH |
| DEFAULT SETTING | | |
| > RESOLUTION | [STANDARD/FINE/FINE PHOTO/ SUPER FINE/S. FINE PHOTO] | FINE |
| > CONTRAST | [NORMAL/DARKEN/LIGHTEN/ PHOTO] | NORMAL |
| SOUND CONTROL | | |
| > ALARM | [1] ON [2] OFF | ON |
| > KEY | [1] ON [2] OFF | ON |
| SELECT LANGUAGE | LANGUAGE OPTIONS DEPENDS ON MACHINE CONFIGURATION | |
| Service Mode | Item | Default Status |
| MODEM TEST | FSK/2400/4800/7200/ | |
| | 9600/12000/14400 bps & 1100/1650/ 1850/2100HZ | N/A |
| DTMF TEST | 1,2,3,4,5,6,7,8,9,0,*,# | N/A |
| CIS SHADING | Adjusts white reference level. Shading adjustment is performed and a COLOR CIS AUTO PEAK TEST printout occurs. | N/A |
| RINGER VOLUME | [LOW/MEDIUM/HIGH] | HIGH |

| DEFAULT SETTING | | |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|
| > RESOLUTION | [STANDARD/FINE/FINWE PHOTO/ SUPER FINE/S.FINE PHOTO] | FINE |
| > CONTRAST | [NORMAL/DARKEN/LIGHTEN/ PHOTO] | NORMAL |
| SOUND CONTROL | | |
| > ALARM | [1] ON [2] OFF | ON |
| > KEY | [1] ON [2] OFF | ON |
| PROGRAM DOWNLOAD | Allows for F/W upgrades. See procedure below. | N/A |
| ROM TEST | Tests Read Only Memory. Provides firmware version and check sum. | N/A |
| AGING TEST | [1] SCANNER AGING Documents loaded in the ADF will be copied. | N/A |
| | [2] PRINTER AGING Prints 2 tests showing print quality. | |
| | OR | |
| | After Loading a white document CIS SHADING adjustment is automatically performed and a COLOR CIS AUTO PEAK TEST printout occurs. PRINTING is then displayed and a sample of solid area printing and vertical printing occurs. | |

MODEM TEST Procedure

The modem will send various transmit signals on the telephone line you can check the fallowing:

- FSK test
- G3 training: 14400, 12000, 9600, 7200, 4800, 2400bpi
- Tones: 1100Hz, 1650Hz, 1850Hz, 2100Hz

DTMF TEST Procedure

DTMF (Dual Tone Multiple Frequency) signal can be checked.

1, 2, 3, 4, 5, 6, 7, 8, 9, 0, *, #

CIS SHADING ADJ. 3.1

 CIS Shading must be performed after performing Firmware update. If not, system may not work properly.

PROGRAM DOWNLOAD

- Used to download F/W into the machines flash ROM from your PC. You can load F/W from Windows or DOS.
- Fwup Procedure from Windows 95/98/NT.
 - a. Go to the directory containing Fwup and the new firmware with a filename similar to "wc48v110."
 - Select Fwup for Windows 95/98 and FwupNT for Windows NT by double clicking your mouse.
 - When the Fwup screen opens you need to select "Verify Information." This checks your machine to make sure the F/W can be upgrade.
 - d. When the machine is ready for the F/W to be upgraded the grayed out selection "Upgrade Now" will turn black. Select "Upgrade Now"
 - e. When the F/W is completed loading the PC screen will display "Writing Complete. Do not turn off until initialize printer!"
 - f. Wait for approximately 2 minutes and press \diamondsuit to set Date & Time.
 - g. Go to step 2.

OR

- 1. Firmware procedure from DOS.
 - Go to DOS mode. On some machines you may not be able to use DOS located in Windows.
 - b. Select Service (Tech.) Mode by pressing [, #, 1, 9, 3, 4.
 - c. Select Program Download by pressing ≡, 04, V, V, V, V, V, V, V, √, ↑, 1. The WorkCentre display will show "Type on the PC"Copy/B Filename LPT1"
 - d. On the PC in DOS mode type "Copy/B (the filename) LPT1" and press \(\bar) \).
 - e. WorkCentre will reset after completing the download of the new firmware.
 - f. Go to step 2.
- 2. Perform CIS Shading adjustment ADJ. 3.1.
- 3. After loading F/W it is good to check to insure that the new F/W is listed on the System List. Press [,19 and check the bttom of the System List.

System Data

Changing System Data

In Service Mode press ■ and one-touch button 01 system data. Then press 1 to choose "TECH" or 2 to enter "User" mode. Press ∧ or ∨ repeatedly to select the desired system data.

When the desired system data appears, enter the corresponding information to change the status of the selected function. Press STOP to return to the date and time display.

Selectable System Data

| (2) User Mode | Item | Default Status |
|-----------------------------|-----------------------------------------------|-------------------|
| PAPER SIZE | [LETTER/A4/ LEGAL] | A4 |
| MESSAGE CONFIRMATION REPORT | [ON/OFF/ ERROR] | ON-ERROR |
| AUTO JOURNAL | [ON/OFF] | OFF |
| REMOTE RCV MF CODE | [0-9] | *9* |
| DIAL MODE | [TONE/PLUSE] | TONE |
| ECM MODE | [ON/OFF] | ON |
| RX REDUCTION | [ON/OFF/ON- VERTICAL REDUCTION ONLY] | ON |
| DISCARD SIZE | [0-30] | 11mm |
| REDIAL INTERVAL | [1-15] | 3minutes |
| REDIALS | [0-9] or [0-2] | 2 |
| ANSWER ON RINGS | [1-7] | 2 |
| SEND FROM MEMORY | [ON/OFF] | ON |
| LOCAL ID. | [ON/OFF] | OFF |
| CONTINUOUS POLL REPORT | [ON/OFF] | OFF |
| FAXPRINT QUALITY | [LQ/DRAFT] | LQ |
| CLOCK MODE | [12/24 HOURS] | 12 HOURS |
| DRPD MODE | [ON/OFF/SET] | OFF |
| | | |

| (1) Service Mode | Item | Default Status |
|----------------------------|-------------------------------------------|-------------------|
| MODEM SPEED | [14400/12000/ 9600/7200/4800/ 2400] | 14.4 KBPS |
| SET TX LEVEL | [0-15] | - 12dBm |
| SET RX LEVEL | [40-50] | - 43dBm |
| FLASH TIME | [100/280/600] | 600ms |
| PAUSE TIME | [1-9] | 3sec |
| ERROR RATE | [5%/10%/20%] | 5% |
| MAKE BREAK RATIO (470 only | [1] 40/60 [2] 33/66 | 40/60 |

MODEM SPEED

Select baud rate of 14400, 12000, 9600, 7200, 4800, or 2400 bps. The lower the baud rate, the larger the acceptable error rate. T30 protocol has a fixed speed of 300 bps in the protocol mode. When the TX speed is set to 14400 or 12000 bps, the RX speed will be either V.17 or V.33. When the TX speed is set to 9600 or 7200 bps, the RX speed will be either V.29 or V.27 ter. When the TX speed is set to 4800 or 2400 bps, the RX speed will be V.27 ter.

FAX TX LEVEL

FCC requires the transmission level be less than -9 dBm. The transmission level can be set between 0 and -15 dBm in 1dBm steps.

Accuracy is +0/-3 dBm.

FAX RX LEVEL

If reception level is set to -43 dBm, receive sensitivity will be between 0 and -43 dBm.

FLASH TIME

Choose telephone flash time 100/280/600 milliseconds.

PAUSE TIME

Sets the length of the pause time from 1 to 9 seconds, when the pause button is pressed.

ERROR RATE

Sets the % of errors allowed during transmission before training down.

MAKE BREAK RATIO

The make and break time during pulse dial.

Firmware Matrix

WorkCentre 480cx, Product Code KU3 (USO/XCL)

| Firmware Version | Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|---------------------------------------|----------------------------------|
| 1.1.0 | Initial Production | N/A | N/A | N/A |
| 1.1.2 | Changes French messages in the LCD. Corrects the color and photo ink drop count available in Service Mode. | N/A | N/A | N/A |
| 1.3.0 | Changes CNF tone detection to reduce the detection of voice as a CNG tone. This will eliminate the interruption of a voice call with fax tones. Improved cartridge detection to accept all specified cartridges as valid. This should eliminate the "(X) CART EMPTY" message when a new cartridge is installed. | | | |

WorkCentre 480cx, Product Code KU4 (XBRA/XLA)

| Firmware Version | Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|---------------------|-----------------------|-----------------------------|---------------------------------------|----------------------------------|
| 2.0.0 | Initial Production | N/A | N/A | N/A |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

WorkCentre 480cx, Product Code KU5 (XE)

| Firmware Version | Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|---------------------|-----------------------|-----------------------------|---------------------------------------|----------------------------------|
| 3.0.0 | Initial Production | N/A | N/A | N/A |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

WorkCentre 470cx, Product Code MC7 (USO/XCL)

| Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|-----------------------|-----------------------------|---------------------------------------|---------------------------------------------------------|
| | | | |
| | | | *** |
| | | | |
| | | | |
| | | Numbers Numbers | Description of Change Numbers Installed Serial Number |

WorkCentre 470cx, Product Code MC8 (XBRA/XLA)

| Firmware Version | Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|---------------------|-----------------------|-----------------------------|---------------------------------------|----------------------------------|
| | | | | |
| | | | | |
| | | | | |
| | | | | |

WorkCentre 470cx, Product Code MC9 (XE)

| Firmware Version | Description of Change | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|---------------------|-----------------------|-----------------------------|---------------------------------------|----------------------------------|
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Modifications

The machine serial number listed identifies the earliest number of the change on the manufactured machine. Refer to the classification for information as to when to use the change. Read the description to determine how the machine will benefit from the modification. Refer to the kit number to order the modification kit. Refer to the bulletin number for additional information.

Refer to the factory and field install serial numbers to determine which modifications were installed at the factory and which were installed in the field.

USO: Modification Classification

M Mandatory

R Install at time of repair

O Optional

N Not for field retrofit. Factory retrofit only.

IXE: Modification Classification

Class 1 Safety modification which must be made in the field immediately; parts are available.

Class 2 Modification made in the field, retroactive on all machine, on next service call.

Class 3 Repair by replacement.

Class 4 Modification incorporated at discretion of local management or to customers requirements.


Class 5 Production only.

| Modification Classification | Description | Kit and Bulletin Numbers | Factory Installed Serial Number | Field Installed Serial Number |
|--------------------------------|-------------|-----------------------------|------------------------------------|----------------------------------|
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Installation

Installing the Document Tray

1. Pull the document tray upward.




2. Fold out the extender on the document tray.




Installing the Document Exit Tra

 Insert the two tabs on the document exit tray into the slots on the front of your machine.




Document Exit T

2. Fold out the extender, if necessary.




Connecting the Telephone Line

1. Plug one end of the telephone line cord into the TEL LINE jack and the other end into a standard phone wall jack.



Connecting an Extension Phone (Optional)

1. Plug one end of the modular cord into the EXT.TEL jack on the left side of your machine.




Plug the other end of the cord into a modular jack on a telephone answering device or a regular telephone to use as an extension.

Connecting the Printer Cable

1. Connect a bi-directional parallel printer cable to the 36 pin printer jack on your machine.

NOTE: Use a parallel cable that is approved for IEEE-1284 bi-directional communications.


- 2. Fasten the metal clips to the parallel cable.
- 3. Connect the other end of the parallel cable to your computer.




Loading Paper

You can load approximately 100 sheets of 20 lb. paper.


1. Pull the APF Extension on the APF all the way up.



2. Fan the paper and insert the paper with the print side facing you and next to the far right paper guide.




. Hold the left paper guide and move it to the right to match the width of the paper



Connecting the AC Power Cord

 Plug one end of the cord into the back of the machine and the other end into a standard, grounded 3-prong AC power outlet.




2. The machine turns on.

Installing the Print Cartridge


Print Cartridge

1. Lift the control panel and open the ADF Door.




2. If you are replacing a used cartridge, remove the old cartridge.


Pull the print cartridge handle toward you until you hear a click, then remove the print cartridge.




3. Remove the new print cartridge from its packaging. Hold the print cartridge by the black areas or colored top only. Do not touch the copper area.




4. Carefully remove the tape covering the printhead. Be sure to remove all the tape.



5. Insert the print cartridge in the carriage.



6. Push the cartridge firmly in the direction of the arrow until it clicks into place.



- 7. After installing the print cartridge, close the ADF Door and the Control Panel.
- 8. Make the required selections using the up and down arrows. Then press ENTER.

THIS PAGE INTENTIONALLY LEFT BLANK

Section Contents

| Introduction | 7-1 |
|------------------------------------------------------|-----|
| Component Location BSD | 7-2 |
| Main PBA Connector BSD | 7-3 |
| Power Supply Connector BSD | 7-4 |
| Control Panel & LCD Connector BSD | 7-5 |
| CIS Connector BSD | 7-6 |
| LIU PBA & Parallel Cable Interface PBA Connector BSD | 7-7 |
| Machine BSD | |
| Connector Pin Assignments | 7-9 |

Introduction

This section contains connector and PWB location drawings, and pin assignment information.

This information is not specific to individual procedures, but is provided for general reference.

Connector numbers are repeated on more than one component.




Figure 7 - 1
Top Rear View




Figure 7 - 2 Rear View




Figure 7 - 3
Rear View




Figure 7 - 4
Rear View




Figure 7 - 5
Rear View

Other

Other 0 0 P2 33 DP 40 Other DCR CTR21 0 P4 P1 **LIU PBA** P3 12 IMP O O P5 Figure 7 - 6 Rear View Jumpers P2, P4 and P5 are XE Only




Figure 7 - 7
Rear View




Figure 7 - 8

Connector Pin Assignments

Main PBA Connectors

Table 7-1. **J1 to Control Panel**

| Pin | Description |
|-----|-------------|
| 1 | GND |
| 2 | +5v |
| 3 | OPE TXD |
| 4 | OPE RST |
| 5 | OPE RXD |

Table 7-2. J2 to Scan Motor

| Pin | Description | |
|-----|-------------|--|
| 1 | TH ND | |
| 2 | TH D | |
| 3 | TH NA | |
| 4 | TH A | |

Table 7-3. J3 to CIS

| Pin | Description | |
|-----|-------------|--|
| 1 | CIS SIG | |
| 2 | GND | |
| 3 | +5V | |
| 4 | VREF ADC | |
| 5 | GND | |
| 6 | CIS SH | |

Table 7-3. **J3 to CIS**

| Pin | Description |
|-----|-------------|
| 7 | GND |
| 8 | CIS CLK |
| 9 | LED |
| 10 | LED |
| 11 | LED |
| 12 | +11.75V |

Table 7-4. J4 to Paper Feed Motor

| Pin | Description | |
|-----|-------------|--|
| 1 | LF A | |
| 2 | LF NA | |
| 3 | LF B | |
| 4 | LF NB | |

Table 7-5. **J5 to Speaker**

| Pin | Description |
|-----|-------------|
| 1 | SPK + |
| 2 | SPK - |

Table 7-6. **J6 to Power Supply**

| Pin | Description |
|-----|-------------|
| 1 | +5VDC |
| 2 | GND |
| 3 | +11.75VDC |
| 4 | GND |
| 5 | GND |
| 6 | +30VDC |

Table 7-7. J7 to LIU PB

| Pin | Description |
|-----|-------------|
| 1 | LINE RX |
| 2 | GND |
| 3 | LINE TX |
| 4 | +11.75VDC |
| 5 | REMOTE |
| 6 | CML 1 |
| 7 | OFF HOOK |
| 8 | RING DETECT |
| 9 | +5VDC |
| 10 | LIU TXD |

Table 7-7. J7 to LIU PBA

| Pin | Description |
|-----|-------------|
| 11 | GND |
| 12 | LIU RXD |

Table 7-8. **J8 to APF Tray Empty Sensor** (480 only)

| Pin | Description |
|-----|-------------|
| 1 | P EMPTY |
| 2 | GND |
| 3 | +5VDC |

Table 7-9. **J10 to ADF Cover Interlock** (480 only)

| Pin | Description |
|-----|-------------|
| 1 | Cover Open |
| 2 | GND |

Table 7-10. J11 Jumper

| Pin | Description |
|-----|---------------|
| 1 | Jumper to pin |
| 2 | Jumper to pin |

Table 7-11. J12 Jumper

| Pin | Description |
|-----|---------------|
| 1 | Jumper to pin |
| 2 | Jumper to pin |

Table 7-12. **CN1 to Parallel Cable Interface PWA**

| Pin | Description |
|-----|-------------|
| 1 | GND |
| 2 | GND |
| 3 | STD |
| 4 | AUTO FD |
| 5 | INIT |
| 6 | SLCT IN |
| 7 | GND |
| 8 | GND |
| 9 | CD0 |
| 10 | CD1 |
| 11 | CD2 |
| 12 | CD3 |
| 13 | CD4 |
| 14 | CD5 |
| 15 | CD6 |
| 16 | CD7 |
| 17 | GND |
| 18 | GND |
| 19 | +5VDC |
| 20 | ACK |
| 21 | PF |
| 22 | BUSY |
| 23 | ERROR |

Table 7-12. **CN1 to Parallel Cable Interface PWA**

| Pin | Description |
|-----|-------------|
| 24 | SLCT |
| 25 | GND |
| 26 | GND |

Table 7-13. JP1 to Carriage/Print Head 1

| Pin | Description |
|-----|-------------|
| 1 | CP9 |
| 2 | GND |
| 3 | CP11 |
| 4 | CP13 |
| 5 | GND |
| 6 | CP14 |
| 7 | CAG1 |
| 8 | CP12 |
| 9 | CP16 |
| 10 | CP10 |
| 11 | GND |
| 12 | CA5 |
| 13 | CA4 |
| 14 | CP0 |
| 15 | GND |
| 16 | CA3 |
| 17 | CP 6 |
| 18 | CP4 |

Table 7-13. JP1 to Carriage/Print Head 1

| Pin | Description |
|-----|-------------|
| 19 | GND |
| 20 | CA2 |
| 21 | CP2 |
| 22 | CA1 |
| 23 | TBD |
| 24 | CB1 |
| 25 | CH1 |
| 26 | AMP_TEMP |
| 27 | CHY |
| 28 | +5VDC |
| 29 | CHX |
| 30 | GND |

Table 7-14. JP2 to Carriage/Print Head 2

| Pin | Description |
|-----|-------------|
| 1 | GND |
| 2 | BA5 |
| 3 | BA4 |
| 4 | TBD |
| 5 | GND |
| 6 | BA3 |
| 7 | TBD |
| 8 | BP4 |
| 9 | GND |

Table 7-14. JP2 to Carriage/Print Head 2

| Pin | Description |
|-----|-------------|
| 10 | BA2 |
| 11 | BP2 |
| 12 | BA1 |
| 13 | BS1 |
| 14 | TBD |
| 15 | CA1 |
| 16 | TBD |
| 17 | CP15 |
| 18 | CA12 |
| 19 | CA7 |
| 20 | CP1 |
| 21 | TBD |
| 22 | GND |
| 23 | CP3 |
| 24 | CP5 |
| 25 | CA9 |
| 26 | GND |
| 27 | CP7 |
| 28 | CAI0 |
| 29 | CA11 |
| 30 | CA12 |

Table 7-15. JP3 to Carriage/Print Head 3

| Pin | Description |
|-----|-------------|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | BA13 |
| 7 | BP15 |
| 8 | TBD |
| 9 | BA7 |
| 10 | BP1 |
| 11 | BA9 |
| 12 | GND |
| 13 | BP3 |
| 14 | CP9 |
| 15 | TBD |
| 16 | GND |
| 17 | BP7 |
| 18 | BA10 |
| 19 | BA11 |
| 20 | GND |
| 21 | BP9 |
| 22 | GND |
| 23 | TBD |
| 24 | BP13 |

Table 7-15. JP3 to Carriage/Print Head 3

| Pin | Description |
|-----|-------------|
| 25 | GND |
| 26 | BP14 |
| 27 | TBD |
| 28 | TBD |
| 29 | BP16 |
| 30 | BP10 |

Table 7-16. JP4 to Carriage Motor

| Pin | Description |
|-----|-------------|
| 1 | CRA |
| 2 | CRNA |
| 3 | |

Carriage Connector to Encoder Sensor

Table 7-17. J1 to Encoder Sensor

| Pin | Description |
|-----|-------------|
| 1 | AMB TEMP |
| 2 | CHY |
| 3 | +5VDC |
| 4 | CHX |
| 5 | GND |

LIU PBA Connectors

Table 7-18. P1 to Main PBA

| Pin | Description |
|-----|-------------|
| 1 | LINE RX |
| 2 | GND |
| 3 | LINE TX |
| 4 | +11.75VDC |
| 5 | REMOTE |
| 6 | CML 1 |
| 7 | OFF HOOK |
| 8 | RING DETECT |
| 9 | +5VDC |
| 10 | LIU TXD |
| 11 | GND |
| 12 | LIU RXD |

Table 7-19. P2 Empty

| Pin | Description |
|-----|-------------|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |

Table 7-19. P2 Empty

| Pin | Description |
|-----|-------------|
| 9 | |
| 10 | |
| 11 | |

Table 7-20. **P3 to Telephone/Extension**Jacks

| Pin | Description |
|-----|------------------------|
| 1 | Line Jack (Yellow) |
| 2 | Line Jack (Black(|
| 3 | |
| 4 | Extension Jack (Red) |
| 5 | Extension Jack (Green) |

Power Supply Connector

Table 7-21. CON 1 to Main PBA

| Pin | Description |
|-----|-------------|
| 1 | +5VDC |
| 2 | GND |
| 3 | +11.75VDC |
| 4 | GND |
| 5 | GND |
| 6 | +30VDC |

Parallel Cable Interface PBA Connectors

Table 7-22. CN1 to Main PBA

| Pin | Description |
|-----|-------------|
| 1 | GND |
| 2 | GND |
| 3 | STD |
| 4 | AUTO FD |
| 5 | INIT |
| 6 | SLCT IN |
| 7 | GND |
| 8 | GND |
| 9 | CD0 |
| 10 | CD1 |
| 11 | CD2 |
| 12 | CD3 |
| 13 | CD4 |
| 14 | CD5 |
| 15 | CD6 |
| 16 | CD7 |
| 17 | GND |
| 18 | GND |
| 19 | +5VDC |
| 20 | ACK |
| 21 | PF |
| 22 | BUSY |

Table 7-22. CN1 to Main PBA

| Pin | Description |
|-----|-------------|
| 23 | ERROR |
| 24 | SLCTR |
| 25 | GND |
| 26 | GND |

Table 7-23. CN2 to Parrallel Cable

| Pin | Description |
|-----|-------------|
| 1 | STD |
| 2 | CD0 |
| 3 | CD1 |
| 4 | CD2 |
| 5 | CD3 |
| 6 | CD4 |
| 7 | CD5 |
| 8 | CD6 |
| 9 | CD7 |
| 10 | ACK |
| 11 | BUSY |
| 12 | PF |
| 13 | SLCT |
| 14 | AUTO FD |
| 15 | |
| 16 | GND |
| 17 | GND |

Table 7-23. CN2 to Parrallel Cable

| Pin | Description |
|-----|-------------|
| 18 | +5VDC |
| 19 | GND |
| 20 | GND |
| 21 | GND |
| 22 | GND |
| 23 | GND |
| 24 | GND |
| 25 | GND |
| 26 | GND |
| 27 | GND |
| 28 | GND |
| 29 | GND |
| 30 | GND |
| 31 | INIT |
| 32 | ERROR |
| 33 | |
| 34 | |
| 35 | |
| 36 | SLCT IN |